

STANDARD CIRCUIT CHART (BY NUMBER)

CIRCUIT	DESCRIPTION *	COLOR	CIRCUIT	DESCRIPTION *	COLOR
1	HORN SWITCH CONTROL	DK BLUE	137	RADIO ANTENNA SWITCH FEED	YELLOW-BLACK
2	RH FRONT TURN SIGNAL LAMP	WHITE-LT BLUE	138	DOOR JAMP SWITCH TO LIGHTS ON RELAY	BROWN-LT BLUE
3	LH FRONT TURN SIGNAL LAMP	LT GREEN-WHITE	139	FUEL PULSE TO MESSAGE CENTER	LT GREEN-PURPLE
4	ALTERNATOR REG. "S" TERM. TO ALTERNATOR "S" TERM.	WHITE-BLACK	140	BACK UP LAMP	BLACK-PINK
5	RH REAR TURN SIGNAL LAMP	ORANGE-LT BLUE	141	CLOCK ADVANCE SWITCH TO MESSAGE CENTER	DK GREEN-LT GREEN
6	HORN RELAY TO HORN	YELLOW-LT GREEN	142	CLOCK SELECT SWITCH TO MESSAGE CENTER	LT BLUE-RED
7	SEAT SWITCH ARM TERM. TO RELAY FIELD TERM.	LT GREEN-YELLOW	143	CHECKOUT SWITCH TO MESSAGE CENTER	LT BLUE-YELLOW
8	TURN SIGNAL FLASHER FEED	ORANGE-YELLOW	144	'AMPLIFIER TO SERVO TRANSDUCER FEED	ORANGE-YELLOW
9	LH REAR TURN SIGNAL LAMP	LT GREEN-ORANGE	145	SERVO SOURCE VACUUM SOLENOID TO CONTROL TRANSISTOR	GRAY-BLACK
10	STOPLAMP SWITCH FEED	LT GREEN-RED	146	SERVO VENT SOLENOID TO CONTROL TRANSISTOR	WHITE-PINK
11	ELECTRONIC SWITCH TO IGNITION COIL NEG. TERMINAL	DK GREEN-YELLOW	147	AMPLIFIER FEEDBACK POTENTIOMETER FEED	PURPLE-LT BLUE
12	HEADLAMP DIMMER SWITCH TO HIGH BEAMS	LT GREEN-BLACK	148	SERVO FEEDBACK POTENTIOMETER SIGNAL TO AMPLIFIER	YELLOW-RED
13	HEADLAMP DIMMER SWITCH TO LOW BEAMS	RED-BLACK	149	SERVO FEEDBACK POTENTIOMETER BASE TO AMPLIFIER	BROWN-LT GREEN
14	HEADLAMP SWITCH TO TAIL LAMPS AND SIDE MARKER LAMPS	BROWN	150	SENSOR SIGNAL TO AMPLIFIER	DK GREEN-WHITE
15	HEADLAMP DIMMER SWITCH FEED	RED-YELLOW	151	SPEED CONTROL ON-OFF SWITCH TO AMPLIFIER	LT BLUE-BLACK
16	IGNITION SWITCH TO IGNITION COIL "BATT." TERMINAL	RED-LT GREEN	152	ARRIVAL SWITCH TO MESSAGE CENTER	LT BLUE-WHITE
17	ASH RECEPTACLE LAMP FEED	WHITE	153	ECONOMY SWITCH TO MESSAGE CENTER	PURPLE-YELLOW
18	SEAT SWITCH TO RELAY FIELD TERMINAL	ORANGE-YELLOW	154	DESTINATION SWITCH TO MESSAGE CENTER	PURPLE-LT GREEN
19	INSTRUMENT PANEL LAMPS FEED	LT BLUE-RED	155	DISTANCE TO EMPTY SWITCH TO MESSAGE CENTER	GRAY-RED
20	DISTRIBUTOR ELECTRONIC CONTROL FEED	WHITE-LT BLUE	156	AVERAGE SPEED SWITCH TO MESSAGE CENTER	GRAY-ORANGE
21	EMA CONTROL TO SPARK RETARD SWITCH	DK GREEN-LT GREEN	157	WINDOW REGULATOR MOTOR TO GROUND	GRAY-BLACK
22	BRAKE FEED	LT BLUE-BLACK	158	KEY WARNING SWITCH TO BUZZER	BLACK-PINK
23	ANTI-THEFT SYSTEM SWITCH FEED	TAN-LT GREEN	159	DOOR JAMB SWITCH TO BUZZER	RED-PINK
24	ANTI-THEFT SWITCH ARM	DK BLUE-ORANGE	160	BUZZER TO WARNING INDICATOR RELAY	WHITE-PINK
25	ANTI-THEFT SWITCH DISARM	DK GREEN-PURPLE	161	MILES/KILOMETERS SWITCH TO MESSAGE CENTER	GRAY-LT BLUE
26	DECK LID SWITCH TO ANTI-THEFT MODULE	WHITE-PURPLE	162	EMERG. BRAKE WARNING LAMP TO EMERG. BRAKE SWITCH	LT GREEN-RED
27	EMA CONTROL TO EGR SWITCH	ORANGE-LT GREEN	163	KEYLESS DOOR LOCK OUTPUT (DRIVER) FROM MODULE	RED-ORANGE
28	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	BLACK-PINK	164	DISTANCE SWITCH TO MESSAGE CENTER	GRAY-WHITE
29	FUEL GAUGE TO FUEL GAUGE SENDER	YELLOW-WHITE	165	ELAPSED TIME SWITCH TO MESSAGE CENTER	WHITE-BLACK
30	CONSTANT VOLTAGE UNIT AND INDICATOR LAMPS FEED	BLACK-LT GREEN	166	RESET SWITCH TO MESSAGE CENTER	WHITE-ORANGE
31	OIL PRESSURE INDICATOR TO OIL PRESSURE SENDING UNIT	WHITE-RED	167	MESSAGE CENTER OUTPUT CLOCK TO DISPLAY	WHITE-YELLOW
32	STARTER CONTROL	RED-LT BLUE	168	5V DO-MESSAGE CENTER TO DISPLAY	WHITE-BLACK
33	STARTER CONTROL TO INTERLOCK MODULE	WHITE-PINK	169	TRANSFORMER POWER-MESSAGE CENTER TO DISPLAY	LT BLUE-PINK
34	HORN CONTROL MODULE TO OVERRIDE SWITCH	LT BLUE-ORANGE	170	WINDOW REGULATOR SWITCH FEED	RED-LT BLUE
35	ALTERNATOR REGULATOR "F" TERMINAL TO ALTERNATOR	ORANGE-LT BLUE	171	CIRCUIT BREAKER TO SEAT LATCH RELAY	BLACK-WHITE
36	ALTERNATOR OUTPUT	YELLOW-WHITE	172	RELAY TO SEAT LATCH SOLENOID	ORANGE
37	BATTERY TO LOAD	YELLOW	173	DOOR SWITCH TO SEAT LATCH RELAY (COIL TERM.)	PINK-WHITE
38	POWER SUPPLY TO BATTERY	BLACK-ORANGE	174	DATA-MESSAGE CENTER TO DISPLAY	DK GREEN-PURPLE
39	TEMP. GAUGE TO TEMP. SENDING UNIT	RED-WHITE	175	RELAY FEED	BLACK-YELLOW
40	CIGAR LIGHTER FEED	LT BLUE-WHITE	176	REAR WINDOW REGULATOR SWITCH FEED	WHITE
41	WARNING LAMP PROVE OUT	BLACK-LT BLUE	177	KEYLESS DOOR LOCK SEAT SWITCH SENSOR TO MODULE	WHITE
42	SWITCH TO WARNING LAMP	RED-WHITE	178	PARITY BIT-DISPLAY TO MESSAGE CENTER	DK GREEN-ORANGE
43	TRAILER STOP LAMPS	DK BLUE	179	HORIZONTAL SEAT REG. MOTOR TO RELAY	YELLOW
44	TURN SIGNAL FLASHER TO TURN SIGNAL SWITCH	LT BLUE	180	HORIZONTAL SEAT REG. MOTOR TO RELAY	RED
45	HOT WATER TEMP. RELAY TO HOT WATER TEMP. SENDING UNIT	YELLOW-RED	181	BLOWER MOTOR FEED	BROWN-ORANGE
46	ELECTRONIC CONTROL UNIT TO ACCELERATION SOLENOID	YELLOW-BLACK	182	THERMOSTAT SWITCH FEED	BROWN-WHITE
47	ELECTRONIC CONTROL UNIT TO DECELERATION SOLENOID	GRAY-ORANGE	183	TONE GENERATOR	TAN-YELLOW
48	BLIND CIRCUIT TERM. IN HARNESS CANNOT BE CHECKED FOR CONT.	(COLOR OPT)	184	AIR COND. SW. (LO) TO AIR COND. BLOWER MOTOR	TAN-ORANGE
49	TRAILER GROUND	WHITE	185	INSIDE DOOR HANDLE SWITCH TO RETRACTOR INHIBITOR MODULE	GRAY-BLACK
50	TRAILER BRAKES	RED	186	DEFOGGER SW. TO DEFOGGER MOTOR	BROWN-LT BLUE
51	SEAT REG. CONTROL SWITCH FEED	BLACK-WHITE	187	INHIBITOR MODULE TO RETRACTOR OVERRIDE SOLENOID	GRAY-RED
52	TRAILER LH TURN SIGNAL	YELLOW	188	HEADLAMP SWITCH TO AUXILIARY LAMPS	WHITE-BLACK
53	COURTESY LAMP SWITCH TO COURTESY LAMP	BLACK-LI BLUE	189	IDLE TRACKING SWITCH FEED	LT BLUE-PINK
54	INTERIOR LAMP SWITCH FEED	LT GREEN-YELLOW	190	THERMACTOR DUMP VALVE FEED	WHITE-RED
55	CARGO LAMP SW. TO CARGO LAMP	BLACK-PINK	191	DEFOGGER SW. TO DEFOGGER MOTOR	DK BLUE-YELLOW
56	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	DK BLUE-ORANGE	192	HEADLAMP SWITCH TO ELECTRONIC CLUSTER DIMMING	BROWN-WHITE
57	GROUND CIRCUIT	BLACK	193	WINDOW REGULATOR RELAY FEED	YELLOW-LT GREEN
58	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	WHITE	194	WINDOW REGULATOR RELAY ACCY FEED	PINK
59	HEATED EXTERIOR MIRROR FEED	DK GREEN-PURPLE	195	TAILLAMP SWITCH FEED	TAN-WHITE
60	CONSTANT VOLTAGE UNIT TO GAUGE	BLACK-LT GREEN	196	HEADLAMP FLASH TO PASS SWITCH FEED	DK BLUE-ORANGE
61	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	YELLOW-RED	197	COOLANT TEMPERATURE SWITCH TO CONTROL RELAY	TAN-ORANGE
62	BATTERY TO HI-BEAM	BROWN-YELLOW	198	A/C PRESSURE SWITCH TO CONTROL RELAY	TAN-YELLOW
63	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	RED	199	MODULE TO NEUTRAL SENSOR SWITCH	LT BLUE-YELLOW
64	TRAILER RH TURN SIGNAL	DK GREEN	200	THERMACTOR DIVERTER VALVE FEED	WHITE-BLACK
65	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	DK GREEN	201	MCV MODULE TO VIP FUNCTION TESTER	TAN-RED
66	KEYLESS DOOR LOCK SWITCH ILLUMINATION FEED	LT BLUE	202	SPEED CONTROL AMPLIFIER TO CRUISE LAMP INTERFACE MODULE	RED-PINK
67	CHOKE RELAY TO CHOKE	GRAY-WHITE	203	CRUISE INDICATING LAMP TO CRUISE LAMP INTERFACE MODULE	ORANGE-LT BLUE
68	ELECTRIC CHOKE FEED	ORANGE-BLACK	204	TANK SELECT CIRCUIT ELECTRONIC FUEL GAUGE	ORANGE-LT GREEN
69	MODULE TO THROTTLE ACTUATOR	RED-LT GREEN	205	BUFFER FUEL LEVEL OUTPUT TO TRIPMINDER	DK BLUE-LT GREEN
70	SUPPLEMENTAL ALTERNATOR STATOR A TERM. TO WINDSHIELD	RED	206	GROUND RETURN TO TOWING VEHICLE	WHITE
71	SUPPLEMENTAL ALTERNATOR STATOR B TERM. TO WINDSHIELD	WHITE	207	MARKER LAMP SWITCH TO MARKER LAMPS	BLACK
72	SUPPLEMENTAL ALTERNATOR STATOR C TERM. TO WINDSHIELD	DK GREEN	208	LOW OIL LEVEL RELAY TO WARNING LAMP	GRAY
73	ELECTRONIC CONTROL UNIT TO WIDE OPEN THROTTLE ACTUATOR	ORANGE-LT BLUE	209	ELECT. ENG. CONTL. MOD. TO TEST CONN #1	WHITE-RED
74	ELECTRONIC CONTROL UNIT TO EXHAUST GAS OXYGEN SENSOR	DK GREEN-YELLOW	210	INDICATOR LAMP TO SWITCH (4x4)	LT BLUE
75	ELECTRONIC CONTROL UNIT TO ENGINE VACUUM SWITCH	DK GREEN-LT GREEN	211	ECU TO VACUUM SWITCH 4	BLACK-PINK
76	KEYLESS DOOR LOCK ILLUMINATION GROUND TO MODULE	BLACK-LT GREEN	213	ECU TO VACUUM SWITCH 2	WHITE-PINK
77	ELECTRONIC CONTROL UNIT TO SOLENOID ACTUATOR	DK BLUE-YELLOW	214	ECU TO VACUUM SWITCH 3	RED-BLACK
78	KEYLESS DOOR LOCK SWITCH DATA BIT 1 TO MODULE	LT BLUE-YELLOW	215	SIGNAL UNIT LAMP TO FUEL SIGNAL RELAY	YELLOW-BLACK
79	KEYLESS DOOR LOCK SWITCH DATA BIT 2 TO MODULE	LT GREEN-RED	216	AUTOLAMP AMPLIFIER TO RHEOSTAT	TAN-LT BLUE
80	ENGINE COMPARTMENT LAMP FEED	BLACK-ORANGE	217	AUTOLAMP AMPLIFIER TO RHEOSTAT	DK BLUE-ORANGE
81	EMISSION CONTROL VALVE TO SWITCH	BROWN-YELLOW	218	AUTOLAMP AMPLIFIER TO SENSOR	WHITE-PURPLE
82	WASHER FLUID LEVEL INDICATOR	PINK-YELLOW	219	HEADLAMP SWITCH TO AUTOLAMP AMPLIFIER	DK GREEN-YELLOW
83	INTERLOCK MODULE TO CENTER BUCKLE SWITCH	WHITE-ORANGE	220	AUTOLAMP AMPLIFIER TO CONTROL SWITCH	PURPLE-ORANGE
84	DECK LID SOLENOID FEED	PURPLE-YELLOW	221	HEADLAMP SWITCH TO SENSOR AND AUTOLAMP AMPLIFIER	ORANGE-WHITE
85	SEAT BELT WARNING TIMER TO L.F. RETRACTOR SWITCH	BROWN-LT BLUE	222	AUTOLAMP AMPLIFIER TO SENSOR	BROWN-LT GREEN
86	SEAT BELT WARNING TIMER TO R.F. SEAT SENSOR	DK BLUE-WHITE	223	ODOMETER SENSOR TO EEC MODULE	TAN-LT GREEN
87	INTERLOCK MODULE TO CENTER SEAT SENSOR SWITCH	TAN-WHITE	224	TRANSMISSION OVERDRIVE SWITCH TO EEC MODULE	TAN-LT BLUE
88	INSTRUMENT PANEL LAMP SWITCH FEED	BLACK-WHITE	225	INJECTION PUMP FUEL TEMPERATURE SENSOR	BLACK-YELLOW
89	FUEL SENSOR GROUND TO E.C.U.	ORANGE	226	LF WINDOW REG. SW. TO LF WINDOW REG. MOTOR	WHITE-BLACK
90	THERMOCOUPLE POS TO EXHAUST SYST. OVERTEMP PROTECT MODULE	DK BLUE-LT GREEN	227	LF WINDOW REG. SW. TO LF WINDOW REG. MOTOR	YELLOW
91	THERMOCOUPLE 1 NEG. TO EXHAUST SYS. OVERTEMP PROTECT MODULE	GRAY-RED	228	ELECTRIC DRIVE COOLING FAN	BROWN-YELLOW
92	THERMOCOUPLE 2 NEG. TO EXHAUST SYS. OVERTEMP PROTECT MODULE	WHITE-BLACK	229	EFE CARBURETOR SPACE FEED	BLACK-YELLOW
93	AIR DUMP VALVE NEG. TO EXHAUST SYS. OVERTEMP MODULE	ORANGE-WHITE	230	COLD START INJECTOR	BLACK-LT GREEN
94	AIR FUEL SENSOR TO E.C.U.	DK GREEN-PURPLE	231	ACCESSORY FEED TO MESSAGE CENTER	BLACK-YELLOW
95	FEED BACK CARE. COIL 1	TAN-RED	232	FUEL METERING CONTROL LEVER ACTUATOR 1 MINUS	BROWN-LT BLUE
96	FEED BACK CARE. COIL 2	TAN-ORANGE	233	THERMOMETER SENSOR FEED	DK BLUE-YELLOW
97	FEED BACK CARE. COIL 3	TAN-LT GREEN	234	THERMOMETER AMBIENT SENSOR RETURN	DK BLUE-WHITE
98	FEED BACK CARE. COIL 4	TAN-LT BLUE	235	LAMP RETURN TO PULSE WITH DIMMER	RED-BLACK
99	AIR PORT SOLENOID SIGNAL	LT GREEN-BLACK	236	FUEL PRESSURE BOOST SOLENOID	RED-YELLOW
100	AIR PUMP SOLENOID SIGNAL	WHITE-RED	237	TRANSMISSION THROTTLE VALVE SOLENOID 1	ORANGE-YELLOW
101	ELECTRONIC CONTROL UNIT TO CANISTER PURGE SOLENOID	GRAY-YELLOW	238	FUEL SUPPLY PUMP RELAY	ORANGE-LT BLUE
102	LH REAR TAIL LAMP BULB OUTAGE	WHITE BASE	239	FUEL INJECTION PUMP POSITION SENSOR	PURPLE-YELLOW
103	RH REAR TAIL LAMP BULB OUTAGE	WHITE-RED	240	COLD START TIMING RETARD SOLENOID	WHITE-RED
104	LH REAR STOP & TURN BULB OUTAGE	LT BLUE-ORANGE	241	DE-ICE SOLENOID CONTROL	LT BLUE-YELLOW
105	RH REAR STOP & TURN BULB OUTAGE	RED-WHITE	243	POWER SERVO TO CLIMATE CONTROL UNIT (MODE)	LT GREEN-ORANGE
106	LOW FUEL INDICATOR	LT BLUE	244	THERMAL SW. TO CLIMATE CONTROL UNIT	YELLOW-WHITE
107	BUCKLE SW. TO CENTER OCCUPANT SEAT SENSOR	LT BLUE-PINK	245	POWER SERVO TO CLIMATE CONTROL UNIT (AMP)	BROWN-LT GREEN
108	LH HEADLAMP BULB OUTAGE	BROWN-LT BLUE	246	POWER SERVO TO CLIMATE CONTROL UNIT (AMP)	PURPLE
109	RH HEADLAMP BULB OUTAGE	PINK-LT BLUE	247	POWER SERVO TO CLIMATE CONTROL UNIT (AMP)	WHITE-YELLOW
110	R AND LH REAR RUNNING LAMP BULB OUTAGE	WHITE-LT GREEN	248	HEATER & A/C CONTROL SW. (DE-ICE) TO CLIMATE CONTROL UNIT	YELLOW-LT BLUE
111	WARNING LAMP TO LIGHTS ON RELAY	BLACK-YELLOW	249	HEATER & A/C CONTROL SW. (LO-NORM) TO CLIMATE CONTROL UNIT	DK BLUE-LT GREEN
112	WARNING LAMP RELAY FEED	BLACK-YELLOW	250	HEATER & A/C CONTROL SW. (LO-NORM) TO POWER SERVO	ORANGE
113	STARTING MOTOR TO STARTING MOTOR RELAY	YELLOW-LT BLUE	251	IGNITION SWITCH TO THERMACTOR TIMER	BROWN-ORANGE
114	FEED TO VACUUM DOOR LOCK SWITCH	TAN-YELLOW HASH	252	THERMACTOR TIMER TO RELAY	TAN-RED
115	VACUUM DOOR LOCK SWITCH TO SOLENOID (LOCK)	LT GREEN	253	START CIRCUIT TO THERMACTOR RELAY	ORANGE-YELLOW
116	VACUUM DOOR LOCK SWITCH TO SOLENOID (UNLOCK)	BROWN-ORANGE	254	OIL PRESSURE SWITCH TO TIMER	DK GREEN-WHITE
117	DOOR LOCK MOTOR (LOCK)	PINK-BLACK	255	THERMACTOR DUMP VALVE FEED	IT. BLUE-RED
118	DOOR LOCK MOTOR (UNLOCK)	PINK-ORANGE	256	TEMPERATURE COMPENSATED PUMP TO PROCESSOR	ORANGE-WHITE
119	DOOR LOCK SWITCH (LOCK)	PINK-YELLOW	257	H L SW. TO CHIMES	WHITE-RED
120	DOOR LOCK SWITCH (UNLOCK)	PINK-LT GREEN	258	LOW OIL LEVEL RELAY TO SENSOR	WHITE-PINK
121	KEYLESS DOOR LOCK SWITCH DATA BIT 3 TO MODULE	YELLOW-BLACK	259	ELECT. ENG. CONTROL MOD. TO THICK FILM IGN. MOD.	BLACK-ORANGE
122	KEYLESS DOOR LOCK SWITCH DATA BIT 4 TO MODULE	YELLOW	260	BLOWER MOTOR TO SWITCH - LO	RED-ORANGE
123	KEYLESS DOOR LOCK SWITCH DATA BIT 5 TO MODULE	RED	261	BLOWER MOTOR TO SWITCH - HI	ORANGE-BLACK
124	KEYLESS DOOR LOCK SWITCH ENABLE FROM MODULE	BROWN	262	STARTING MOTOR RELAY TO IGNITION COIL 1" TERM.	BROWN-PINK
125	MAP LAMP SWITCH TO RH MAP LAMP	BROWN-YELLOW	263	CLICKER RELAY TERM. NO. 4 TO AIR VALVE ASSY.	PURPLE-LT BLUE
126	COURTESY LAMP SW. TO INSTR. PANEL COURTESY LAMP	BLACK-ORANGE	264	ELECT. ENG. CONTL. MOD. TO IDLE SPD. CONTL. MOTOR #1	WHITE-LT BLUE
127	COURTESY LAMP SW. TO "C" PILLAR LAMPS	BLACK-LT BLUE	265	ELECT. ENG. CONTL. MOD. TO IDLE SPD. CONTL. MOTOR #2	LT GREEN-WHITE
128	BRAKE FLUID LEVEL UNIT TO MESSAGE CENTER	PURPLE-YELLOW	266	MEMORY SEAT SWITCH ENABLE	PURPLE-WHITE
129	KEYLESS DOOR LOCK OUTPUT FROM MODULE	LT GREEN	267	MEMORY SEAT SWITCH POSITION #1	BROWN-LT GREEN
130	HEADLAMP BULB OUTAGE TO MESSAGE CENTER	RED-LT GREEN	268	MEMORY SEAT SWITCH POSITION #2	BLACK-ORANGE
131	CIGAR LIGHTER LAMP FEED	PURPLE-ORANGE	269	HEATER BLOWER MOTOR TO SWITCH (MEDIUM)	LT BLUE-ORANGE
132	TAIL LAMP BULB OUTAGE TO MESSAGE CENTER	ORANGE-BLACK	270	MEMORY SEAT SWITCH SET	BROWN-ORANGE
133	RELAY TO MAP LAMP SWITCH	TAN-RED	271	MEMORY SEAT SWITCH LAMP ENABLE	LT GREEN-WHITE
134	KEYLESS DOOR LOCK OUTPUT (ALL) FROM MODULE	WHITE	272	MEMORY SEAT SWITCH LAMP DRIVE	WHITE-ORANGE
135	STOP AND TURN BULB OUTAGE TO MESSAGE CENTER	YELLOW-RED	273	TO ELECTRONIC CLUSTER FROM ENGLISH/METRIC SWITCH IN KEYBOARD	BROWN
136	SPEED INPUT TO MESSAGE CENTER	YELLOW-LT BLUE	274	SWITCH OFF TO RELAY	ORANGE
			275	SWITCH ON TO RELAY	YELLOW
			276	SWITCH FEED	BROWN
			277	AMPLIFIER SPEAKER SWITCH TO LEFT REAR SPEAKER	LT BLUE-BLACK
			278	AMPLIFIER SPEAKER SWITCH FEED TO RIGHT REAR SPEAKER	PURPLE-WHITE

* IN SOME CASES, THERE MAY BE ADDITIONAL CIRCUIT FUNCTIONS INCLUDED IN THE CIRCUIT DESCRIPTION LISTED.

STANDARD CIRCUIT CHART (BY NUMBER)

CIRCUIT	DESCRIPTION *	COLOR
279	SPEAKER VOICE COIL FEED FRONT (R. CHANNEL) AMP INPUT	WHITE-RED
280	SPEAKER VOICE COIL FEED FRONT (LEFT CHANNEL) AMP INPUT	LT GREEN
281	SPEAKER VOICE COIL RETURN AMP INPUT	WHITE
285	TO ELECTRONIC CLUSTER FROM EXPANDED FUEL IN KEYBOARD	ORANGE
286	TO ELECTRONIC CLUSTER FROM TRIP RESET SWITCH IN KEYBOARD	YELLOW
287	SPEAKER VOICE COIL RETURN	BLACK-WHITE
288	TO ELECTRONIC CLUSTER FROM TRIP RECALL SWITCH IN KEYBOARD	PURPLE
289	TO ELECTRONIC CLUSTER FROM GAUGE SELECT SWITCH IN KEYBOARD	WHITE
290	12 GA FUSE LINK	GRAY
291	16 GA FUSE LINK	BLACK
292	18 GA FUSE LINK	BROWN
293	INSTRUMENT PANEL ILLUMINATION CONTROL MODULE FEED	ORANGE-RED
294	FUSED ACCY FEED #3	WHITE-LT BLUE
295	ELECTRONIC CLUSTER ACCESSORY FEED	LT. BLUE-PINK
296	FUSED ACCY FEED #1	WHITE-PURPLE
297	ACCY FEED FROM IGNITION SWITCH	BLACK-LT GREEN
298	FUSED ACCY FEED #2	PURPLE-ORANGE
299	14 GA FUSE LINK	DK GREEN
300	16 GA FUSE LINK	ORANGE
301	18 GA FUSE LINK	RED
302	20 GA FUSE LINK	DK BLUE
303	12 GA FUSE LINK	YELLOW
304	FEEDBACK CARBURETOR COIL "A"	BROWN
305	EEC MODULE TO TIME METER	LT BLUE-PINK
306	SEAT REG. SW. TO HORIZ. SOLENOID BATT. TERM	LT BLUE
307	SEAT REG. SW. TO VERT. SOLENOID BATT. TERM	WHITE
308	HI-TEMP SWITCH TO MCU MODULE	LT BLUE-ORANGE
309	LO-TEMP SWITCH TO MCU MODULE	ORANGE-RED
310	MCU MODULE TO KNOCK SENSOR	YELLOW-RED
311	MCU MODULE TO KNOCK SENSOR	DK GREEN-ORANGE
312	FUEL METERING CONTROL LEVER ACTUATOR 2 PLUS	WHITE-PURPLE
313	LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT FRONT WINDOW REGULATOR MOTOR	. YELLOW-BLACK
314	LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT FRONT WINDOW REGULATOR MOTOR	RED-BLACK
315	TRANSMISSION THROTTLE VALVE SOLENOID 2	DK GREEN-PURPLE
316	LEFT FRONT WINDOW REGULATOR SWITCH TO LEFT REAR WINDOW REGULATOR MOTOR	YELLOW-LT BLUE
317	LEFT FRONT WINDOW REGULATOR SWITCH TO LEFT REAR WINDOW REGULATOR MOTOR	RED-LT BLUE
318	EXHAUST BACK PRESSURE VALVE ACTUATOR	GRAY-RED
319	LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT REAR WINDOW REGULATOR MOTOR	YELLOW-BLACK
320	LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT REAR WINDOW REGULATOR MOTOR	RED-BLACK
321	AIR CONDITIONER CLUTCH RELAY	GRAY-WHITE
322	IDLE SPEED CONTROL TO EGR VENT SOLENOID	RED-ORANGE
323	IDLE SPEED CONTROL TO EGR VACUUM SOLENOID	ORANGE-BLACK
324	TRANSMISSION OVERDRIVE SWITCH TO HEAT MODULE	YELLOW-LT GREEN
325	CRANK ENABLE TO IGNITION MODULE	DK BLUE-ORANGE
326	FUSE PANEL FEED TO RELAY	WHITE-PURPLE
327	DIESEL WATER IN FUEL SENDER TO WARNING LAMP GROUND	BLACK-ORANGE
328	WINDOW REG. MASTER CONT. SW. TO WINDOW REG. SW. FEED	RED-YELLOW
329	CRANK ENABLE RELAY	PINK
330	POWER STEERING PRESSURE SWITCH	YELLOW-LT GREEN
331	WIDE OPEN THROTTLE A/C CUTOUT SWITCH	RED
332	TIME DELAY RELAY	WHITE
333	WINDOW REG. SW. TO WINDOW REG. MOTOR	YELLOW-RED
334	WINDOW REG. SW. TO WINDOW REG. MOTOR	RED-YELLOW
335	AFTER GLOW RELAY TO DIESEL CONTROL SWITCH	ORANGE-LT BLUE
336	POWER RELAY TO GLOW PLUGS (RIGHT BANK)	BLACK-LT GREEN
337	POWER RELAY TO GLOW PLUGS (LEFT BANK)	ORANGE-WHITE
338	DIESEL CONTROL SWITCH TO LAMP CONTROL RELAY	BROWN-PINK
339	DIESEL CONTROL SWITCH TO POWER RELAY & LAMP CONTROL RELAY	GRAY
340	ANTI-THEFT MODULE TO ALARM RELAY	RED-LT BLUE
341	DOOR OPENING WARNING TO ANTI-THEFT MODULE	ORANGE-WHITE
342	START INTERRUPT RELAY TO ANTI-THEFT MODULE	LT GREEN-PURPLE
343	WARNING LAMP TO ANTI-THEFT MODULE	DK BLUE-LT GREEN
344	DOOR AJAR SWITCH TO INDICATOR LAMP LEFT FRONT GROUND	BLACK-YELLOW
345	DOOR AJAR SWITCH TO INDICATOR LAMP RIGHT FRONT GROUND	BLACK-PINK
346	DOOR AJAR SWITCH TO INDICATOR LAMP RIGHT REAR GROUND	BLACK-WHITE
347	COMPRESSOR CLUTCH FEED	BLACK-YELLOW
348	THERMOSTATIC SW. TO AIR COND. SW. SELECTOR TERM.	LT GREEN-PURPLE
349	CRANKSHAFT POSITION SENSOR FEED	DK BLUE
350	CRANKSHAFT SENSOR SIGNAL RETURN	GRAY
351	SENSOR SIGNAL FEED	ORANGE-WHITE
352	EGR VALVE POSITION FEED	BROWN-LT GREEN
353	VEHICLE SPEED SENSOR FEED	LT BLUE
354	ENGINE COOLANT TEMPERATURE SENSOR FEED	LT GREEN-YELLOW
355	THROTTLE ANGLE POSITION SENSOR FEED	DK GREEN-LT GREEN
356	BAROMETRIC PRESSURE SENSOR FEED	DK BLUE-LT GREEN
357	CARBURETOR AIR TEMPERATURE SENSOR FEED	LT GREEN-PURPLE
358	MANIFOLD ABSOLUTE PRESSURE SENSOR FEED	LT GREEN-BLACK
359	SENSOR SIGNAL RETURN	BLACK-WHITE
360	EGR VALVE TO EEC MODULE	DK GREEN
361	POWER RELAY TO EEC MODULE	RED
362	EGR VALVE TO EEC MODULE FEED	YELLOW
363	DOOR AJAR SWITCH TO INDICATOR LAMP LEFT REAR GROUND	BLACK-LT BLUE
364	BLOWER MOTOR RELAY FEED	BLACK-LT GREEN
365	FUEL LEVEL WARNING RELAY FEED	LT BLUE-RED
366	FUEL WARNING RELAY CONTROL	RED-BLACK
367	FUEL LEVEL RECEIVER TO FUEL LEVEL WARNING RELAY (REG. TERM.)	DK GREEN-WHITE
368	RADIO "SEEK UP"	RED-BLACK
369	VACUUM SOLENOID TO TEMP. SW.	BROWN-ORANGE
370	RADIO SEEK "DOWN"	ORANGE-BLACK
371	BLOWER MOTOR RELAY TO MOTOR	PINK-WHITE
372	RADIO MEMORY SEEK	BROWN-ORANGE
373	TO ELECTRONIC CLUSTER FROM GROUND IN KEYBOARD	BLACK
374	DOOR AJAR RELAY TO DOOR SWITCH	BROWN
375	MOVABLE STEERING COLUMN SOLENOID FEED	YELLOW-LT GREEN
376	ELECT. ENG. CONTL. MOD. TO IDLE SPD. CONTL. MOTOR #3	BROWN-WHITE
377	ELECT. ENG. CONTL. MOD. TO EXHAUST HEAT CONTRL SOC.	WHITE
378	ELECT. ENG. CONTL. MOD. TO WIDE OPEN THROTTLE KICKER SOC.	RED-BLACK
379	TURN SIGNAL SWITCH TO RH CORNERING LAMP	BROWN-WHITE
380	TURN SIGNAL SWITCH TO LH CORNERING LAMP	PURPLE-YELLOW
381	MOVABLE STEERING COLUMN SOLENOID TO COURTESY LAMP SWITCH	ORANGE-WHITE
382	ELECT. ENG. CONTL. MOD. TO TEST CONN #2	YELLOW-BLACK
383	EMERGENCY WARNING FLASHER FEED	RED-WHITE
384	ELECT. ENG. CONTL. MOD. TO IDLE SPD CONTL. MOTOR #3	PINK-ORANGE
385	FLASHER TO EMERGENCY WARNING SWITCH	WHITE-RED
386	ELECT. ENG. CONTL. MOD. TO ELECTRO DRIVE FAN	LT BLUE
387	READING LAMP SWITCH TO READING LAMP (LH)	LT GREEN
388	REAR VIEW OUTSIDE MIRROR FEED	RED
389	R.F. DOOR LOCK SWITCH TO L.F. DOOR LOCK SWITCH	DK. GREEN-LT GREEN
390	R.F. DOOR UNLOCK SWITCH TO L.F DOOR UNLOCK SWITCH	DK BLUE-WHITE
391	CHOKE RELAY TO MCU MODULE	WHITE-YELLOW
392	ELECTRIC PVS TO MCU MODULE	WHITE-ORANGE
393	THROTTLE KICKER RELAY TO MCU MODULE	WHITE-BLACK
394	ANEROID SWITCH TO MCU MODULE	GRAY-LT BLUE
395	SPARK MODULE TO MCU MODULE	GRAY-ORANGE
396	FUEL 1 GROUND TO TACH/GAUGE MODULE	BLACH-ORANGE
397	SIGNAL GROUND TO TACH/GAUGE MODULE	BLACK-WHITE
398	TACHOMETER GROUND TO TACH/GAUGE MODULE	BLACK-YELLOW
399	HEATER BLOWER SWITCH FEED	BROWN-YELLOW
400	SAFETY RELAY LOAD TERM. TO WIND. REG. SW. FEED	LT BLUE-BLACK
401	LIMIT SW. TO BACK WINDOW REG. MOTOR	GRAY-BLACK
402	WINDOW REG. SW. TO BACK WINDOW REG. MOTOR	GRAY-RED
403	WINDOW REG. SW. TO WINDOW REG. MOTOR	GRAY-WHITE
404	WINDOW REG. SW. TO BACK WINDOW SW.	PURPLE-LT GREEN
405	WINDOW REG. SW. TO BACK WINDOW SW.	PURPLE-LT BLUE

CIRCUIT	DESCRIPTION *	COLOR
406	WINDOW REG. SW. TO BACK WINDOW AUX. SW.	TAN
407	WINDOW REG. SW. REAR TO LIMIT SW.	TAN-BLACK
408	WINDOW REG. SW. FRONT TO LIMIT SW.	TAN-RED
409	PRESSURE SWITCH TO KEY SWITCH	TAN-BLACK
410	REARVIEW OUTSIDE MIRROR UP	YELLOW
411	REARVIEW OUTSIDE MIRROR DOWN	DK GREEN
412	REARVIEW OUTSIDE MIRROR COUNTER CLOCKWISE	WHITE
413	REARVIEW OUTSIDE MIRROR CLOCKWISE	LT BLUE
414	AIR SOLENOID CONTROL R.F.	ORANGE-RED
415	AIR SOLENOID CONTROL L.F.	LT GREEN-ORANGE
416	AIR SOLENOID CONTROL-REAR	LT BLUE-BLACK
417	AIR SUSPENSION SWITCH FEED	PURPLE-ORANGE
418	AIR SUSPENSION CONTROL MODULE FEED	DK GREEN-YELLOW
419	AIR SUSPENSION MANFUNCTION WARNING LAMP	DK GREEN-LT GREEN
420	AIR COMPRESSOR POWER RELAY CONTROL	DK BLUE-YELLOW
421	AIR COMPRESSOR VENT SOLENOID	PINK
422	AIR SUSPENSION HEIGHT SENSOR HI-L.F.	PINK-BLACK
423	AIR SUSPENSION HEIGHT SENSOR LO-L.F	PURPLE-LT GREEN
424	AIR SUSPENSION HEIGHT SENSOR HI-R.F	TAN
425	AIR SUSPENSION HEIGHT SENSOR LO-R.F	BROWN-PINK
426	FRONT AIR SUSPENSION HEIGHT SENSOR FEED	RED-BLACK
427	AIR SUSPENSION HEIGHT SENSOR HI-REAR	PINK-BLACK
428	AIR SUSPENSION HEIGHT SENSOR LO-REAR	ORANGE-BLACK
429	REAR AIR SUSPENSION HEIGHT SENSOR FEED	PURPLE-LT GREEN
430	AIR SUSPENSION SYSTEM GROUND	GRAY
431	AIR SUSP. MOD. TO L.F. HEIGHT SENSOR	PINK-WHITE
432	AIR SUSPENSION ELECTRONICS GROUND	BLACK-PINK
433	FUEL PUMP BYPASS	LT BLUE-RED
434	RELAY TO DAY/NIGHT ILLUMINATION LAMPS	LT BLUE-BLACK
435	POSITION SENSE RETURN	YELLOW-LT BLUE
436	REAR TILT POSITION SENSE	RED-LT GREEN
437	POSITION SENSE ENABLE	YELLOW-LT GREEN
438	HORIZONTAL POSITION SENSE	RED-WHITE
439	SEAT PROCESSOR TO RECLINER MOTOR "UP"	YELLOW-WHITE
440	SEAT PROCESSOR TO RECLINER MOTOR "DOWN"	RED-LT BLUE
441	FRONT TILT POSITION SENSE	GRAY-BLACK
442	SEQUENTIAL LH REAR INBOARD TURN SIGNAL LAMP	LT GREEN-ORANGE
443	SEQUENTIAL LH REAR CENTER TURN SIGNAL LAMP	LT GREEN-RED
444	SEQUENTIAL LH REAR OUTBOARD TURN SIGNAL LAMP	LT GREEN-BLACK
445	SEQUENTIAL RH REAR INBOARD TURN SIGNAL LAMP	ORANGE-LT BLUE
446	SEQUENTIAL RH REAR CENTER TURN SIGNAL LAMP	ORANGE-WHITE
447	SEQUENTIAL RH REAR OUTBOARD TURN SIGNAL LAMP	ORANGE-RED
448	ANTENNA SWITCH TO ANTENNA RELAY	ORANGE-YELLOW
449	RADIO SWITCH TO ANTENNA RELAY	BROWN-ORANGE
450	SEAT BELT WARNING INDICATOR LAMP FEED	DK GREEN-LT GREEN
451	BATTERY TO AUTOMATIC ANTENNA SWITCH	LT BLUE-YELLOW
452	SEAT PROCESSOR ASSY TO FRONT MOTOR LH	GRAY-RED
453	TRANSMISSION DIAGNOSTIC	PURPLE
454	IGN. SW. COIL TERM. TO CIRCUIT BREAKER	RED-LT GREEN
455	SWITCH TO VALVE	GRAY-RED
456	AUX WATER VALVE FEED	WHITE-LT GREEN
457	BRAKE WEAR SENSOR	TAN-BLACK
458	TURN SIGNAL SWITCH TO INDICATOR RELAY	ORANGE-BLACK
459	INDICATOR RELAY TO FLASHER	ORANGE-LT GREEN
460	HORN SWITCH FEED	YELLOW-LT BLUE
461	MODULE TO RELAY	ORANGE
462	MODULE TO RELAY	PURPLE
463	ELECTRIC SHIFT MODULE TO NEUTRAL START SWITCH	RED-WHITE
464	MODULE TO LIGHT	BLACK-PINK
465	MODULE TO SWITCH	WHITE-LT BLUE
466	DIESEL CONTROL MODULE FEED	PINK-ORANGE
467	PRESSURE SWITCH TO INERTIA SWITCH	GRAY-YELLOW
468	EATC LH SUNLOAD SENSOR POSITIVE	BROWN
469	SEAT BELT WARNING SWITCH FEED	LT GREEN
470	THERMO SWITCH TO CONTROL MODULE	PINK-BLACK
471	DROPPING RESISTOR TO RELAY #2	ORANGE-LT GREEN
472	GLOW PLUG TO CONTROL MODULE	YELLOW-BLACK
473	CONTROL MODULE TO OIL PRESSURE SWITCH	LT GREEN-BLACK
474	STOPLAMP RELAY FEED	PINK-BLACK
475	STOPLAMP SW. TO STOPLAMP RELAY (COIL TERM.)	DK GREEN-WHITE
476	EATC LH SUNLOAD SENSOR NEGATIVE	BROWN-YELLOW
477	FOG LAMP SWITCH TO FOG LAMP RELAY	LT BLUE-BLACK
478	FOG LAMP SW. TO FOG LAMP	TAN-ORANGE
479	EATC RH SUNLOAD SENSOR POSITIVE	PURPLE BASE
480	CLUTCH SWITCH TO EFI MODULE	PURPLE-YELLOW
481	EFI MODULE TO CLUTCH SWITCH	GRAY-YELLOW
482	FUEL FILLER DOOR RELEASE SWITCH TO FUEL FILLER DOOR RELEASE SOLENOID	WHITE-PINK
483	EATC RH SUNLOAD SENSOR NEGATIVE	GRAY
484	LIQUID CRYSTAL DISPLAY	ORANGE-BLACK
485	IGNITION SWITCH ACCY TERM. TO DECK LID OPEN WARNING LAMP	BROWN-PINK
486	DECK LID OPEN WARNING LAMP TO DECK LID OPEN SWITCH	BROWN-WHITE
487	READING LAMP SWITCH TO READING LAMP	PINK-ORANGE
488	DIESEL CONTROL MODULE GROUND RETURN	BLACK-LT BLUE
489	ELECTRONIC CLUSTER IGNITION RUN FEED	PINK-BLACK
490	POWER LUMBAR FEED	RED
491	POWER "THIGH" BOLSTER UP	YELLOW
492	POWER "THIGH" BOLSTER DOWN	BROWN
493	HCU (MAIN) TO MODULE	BLACK-PINK
494	TURN SIGNAL RELAY TO TURN SIGNAL FLASHER	TAN-LT GREEN
495	VALVE #1 TO MODULE	TAN
496	VALVE #2 TO MODULE	ORANGE
497	VALVE #3 TO MODULE	WHITE
498	VALVE #4 TO MODULE	PINK
499	VALVE #5 TO MODULE	GRAY-BLACK
500	HEADLAMP DIMMER SWITCH TO HEADLAMP DIMMER RELAY	PURPLE
501	ELECTRONIC FUEL GAGE TO MESSAGE CENTER	LT BLUE
502	HEADLAMP DIMMER RELAY TO HEADLAMP DIMMER SWITCH	GRAY
503	HEADLAMP DIMMER RELAY TO FUSE HOLDER	LT BLUE
504	FUSE HOLDER TO HEADLAMP DIMMER AMPLIFIER	DK BLUE-WHITE
505	HEADLAMP DIMMER SWITCH TO HEADLAMP DIMMER AMPLIFIER	GRAY-YELLOW
506	MPH/KPH SWITCH TO MESSAGE CENTER	RED
507	AMPLIFIER TO RHEOSTAT	YELLOW
508	RHEOSTAT TO SENSOR	WHITE
TA9	AIR COND. CONDENSER THERMAL SWITCH FEED	TAN-YELLOW
510	VALVE #6 TO MODULE	TAN-RED
511	STOPLAMP SWITCH TO TURN SIGNAL SWITCH	LT GREEN
512	BRAKE FLUID RES. SWITCH TO MODULE	TAN-LT GREEN
513	POWER RELAY COIL TO MODULE	BROWN-PINK
514	RH FRONT SENSOR (HIGH) TO MODULE	YELLOW-RED
515	RESISTOR TO BLOWER MOTOR (HI)	ORANGE-RED
516	RH FRONT SENSOR (LOW) TO MODULE	YELLOW-BLACK
517	CIRCUIT BREAKER (LOAD TERM) TO CONTROL SWITCH (BATT. TERM)	BLACK-WHITE
518	REAR SENSOR (HIGH) TO MODULE	LT GREEN-RED
519	LH REAR SENSOR (LOW) TO MODULE	LT GREEN-BLACK
520	SEAT BELT WARNING LAMP TO WARNING LAMP SWITCH	PURPLE-WHITE
521	LH FRONT SENSOR (HIGH) TO MODULE	TAN-ORANGE
522	LH FRONT SENSOR (LOW) TO MODULE	TAN-BLACK
523	RH REAR SENSOR (HIGH) TO MODULE	RED-PINK
524	RH REAR SENSOR (LOW) TO MODULE	PINK-BLACK
525	SPLICE TO MODULE	ORANGE-YELLOW
526	CORNERING LAMP SWITCH FEED	BLACK-WHITE
527	HEADLAMP DIMMER SWITCH OVERRIDE TO RHEOSTAT	RED
528	POWER RELAY TO MODULE GROUND	ORANGE-YELLOW
529	SPLICE #2 TO MODULE	YELLOW-LT GREEN
530	SPLICE #3 TO POWER RELAY	LT GREEN-YELLOW
531	SPLICE TO DIODE	ORANGE-YELLOW
532	SPLICE TO POWER RELAY	ORANGE-YELLOW
533	POWER RELAY TO FUSE LINK	TAN-RED
534	SPLICE #3 TO PRESSURE SWITCH	YELLOW-LT GREEN
535	PRESSURE SWITCH TO MODULE	LT BLUE-RED
536	BLOWER MOTOR RELAY (LOAD TERM) TO BLOWER MOTOR	BLACK-LT GREEN
537	FUSE LINK TO MOTOR RELAY	TAN-YELLOW
538	MOTOR TO MOTOR RELAY	GRAY-RED
539	PRESSURE SWITCH TO MOTOR RELAY	PINK-LT BLUE
540	L.H. REMOTE MIRROR MOTOR FEED - C.W.	RED
541	L.H. REMOTE MIRROR MOTOR FEED - C.C.W.	DK BLUE
542	L.H. REMOTE MIRROR SOLENOID CONTROL	YELLOW
543	R.H. REMOTE MIRROR MOTOR FEED - C.W.	DK GREEN
544	R.H. REMOTE MIRROR MOTOR FEED - C.C.W.	PURPLE
545	R.H. REMOTE MIRROR SOLENOID CONTROL	WHITE
546	SPLICE #3 TO POWER RELAY	DK GREEN-YELLOW
547	PRESSURE SWITCH TO FLUID RES. SWITCH	LT GREEN-YELLOW
548	GROUND STUD TO SPLICE #2	YELLOW-LT GREEN
549	FLUID WARNING SWITCH TO PRESSURE SWITCH	BROWN-WHITE

* IN SOME CASES, THERE MAY BE ADDITIONAL CIRCUIT FUNCTIONS INCLUDED IN THE CIRCUIT DESCRIPTION LISTED.

STANDARD CIRCUIT CHART (BY NUMBER)

CIRCUIT	DESCRIPTION *	COLOR
550	FLUID SWITCH TO GROUND STUD	YELLOW-LT GREEN
551	SPLICE #2 TO SPLICE #3	YELLOW-LT GREEN
552	SPLICE #2 TO COUP GROUND "B"	YELLOW-LT GREEN
554	POWER RELAY BATTERY FEED	YELLOW-BLACK
555	FUEL INJECTOR #1 CYLINDER	TAN
556	FUEL INJECTOR #2 CYLINDER	WHITE
557	FUEL INJECTOR #3 CYLINDER	BROWN-YELLOW
558	FUEL INJECTOR #4 CYLINDER	BROWN-LT BLUE
559	FUEL INJECTOR #5 CYLINDER	TAN-LT BLUE
560	FUEL INJECTOR #6 CYLINDER	LT GREEN
561	FUEL INJECTOR #7 CYLINDER	TAN-ORANGE
562	FUEL INJECTOR #8 CYLINDER	LT BLUE
563	SPEED SENSOR LO V REF TO SPEEDO TACH MODULE	ORANGE-YELLOW
564	FUEL SIGNAL TACH MODULE TO FUEL COMPUTER	BROWN
565	SPEED SIGNAL SPEEDO TACH MODULE TO FUEL COMPUTER	BLACK-WHITE
566	PROCESSOR TO THERMACTOR CLUTCH RELAY	WHITE-RED
567	THERMACTOR CLUTCH RELAY TO CLUTCH	WHITE-BLACK
568	ALTERNATOR RELAY TO ALTERNATOR REGULATOR	LT GREEN
569	STOPLAMP SWITCH TO HI MOUNT STOPLAMP	DK GREEN
570	DEDICATED GROUND	BLACK-WHITE
571	REMOTE CONVENIENCE SELF DIAGNOSTIC GROUND	BLACK-ORANGE
572	ENGLISH METRIC SIGNAL TO MULTIGAGE	ORANGE-BLACK
573	CENTER REAR TAILLAMP BULB OUTAGE	BLACK-ORANGE
574	EXTENDED USEFUL LIFE SENSOR TO WARNING LAMP	BROWN-WHITE
575	RELAY TO ATC CONTROL	YELLOW-BLACK
576	REAR LAMP TO TRAILER RELAY FEED	DK GREEN
577	AIR SUSPENSION SYSTEM GROUND	LT GREEN-RED
578	AIR COMPRESSOR VENT SOLENOID	LT BLUE-PINK
579	HEATED WINDSHIELD CONTROL TO ELECT ALTERNATOR REGULATOR	BLACK-ORANGE
580	HEATED WINDSHIELD CONTROL TO ALT POWER RELAY	BROWN
581	HEATED WINDSHIELD CONTROL TO ALT STATOR TERM	RED
582	HEATED WINDSHIELD SWITCH TO HEATED WINDSHIELD CONTROL	ORANGE
583	ALT POWER RELAY TO CONTROL MODULE	YELLOW
584	POWER FEED DECEL TIMER TO THROTTLE KICKER	DK GREEN-PURPLE
585	HEATED WINDSHIELD CONTROL TO EEC AIR COND TERM	PURPLE
586	CONVERTIBLE TOP RELAY TO SWITCH	YELLOW
587	WINDSHIELD WIPER INTERMITTENT GOVERNOR FEED	BLACK-WHITE
588	CONVERTIBLE TOP RELAY TO SWITCH	PURPLE
589	WINDSHIELD WIPER SWITCH TO INTERMITTENT GOVERNOR GROUND	ORANGE
590	INTERMITTENT GOVERNOR TO W/S WIPER SWITCH	DK BLUE-WHITE
591	DCP MODULE TO WASHER RELAY	BROWN-YELLOW
592	DCP MODULE TO WIPER PARK OVER-RIDE RELAY	BROWN-LT GREEN
593	.DCP MODULE TO WIPER GOVERNOR RELAY	RED-ORANGE
594	DCP MODULE TO WIPER HI-LO RELAY	ORANGE-LT GREEN
595	DCP MODULE CONTROL INTERFACE TO RADIO	LT BLUE-RED
596	DCP MODULE SIGNAL GROUND TO RADIO	BLACK
597	DCP MODULE TRIP SCAN HIGH TO TRIPMINDER	LT GREEN-BLACK
598	DCP MODULE TRIP SCAN LOW TO TRIPMINDER	LT GREEN-PURPLE
599	MODULE TO SOLENOID	PINK-LT GREEN
600	FEED TO FAILURE SWITCH	DK BLUE
601	BRAKE SKID CONTROL MODULE FEED	LT BLUE-PINK
602	COIL TERM. OF IGN. SW. TO BRAKE SKID CONTROL MODULE	RED-LT GREEN
603	FAILURE WARNING LIGHT	DK GREEN
604	SKID CONTROL MODULE TO RH WHEEL SENSOR HI	ORANGE-RED
605	SOLENOID	RED
606	SH-IRE TRACK DIAGNOSTIC	WHITE-LT BLUE
607	DIESEL COLD ADVANTAGE	GRAY-RED
608	AIR BAG DIAGNOSTIC MODULE TO RELAY INDICATOR LAMP	BLACK-YELLOW
609	AIR BAG READY INDICATOR LAMP TO AIR BAG FLASHER	ORANGE-YELLOW
610	AIR BAG DIAGNOSTIC MODULE TO AIR BAG FLASHER	ORANGE-LT GREEN
611	AIR BAG READY INDICATOR L (DEPLOY) TO SAFING SENSOR	WHITE-ORANGE
612	AIR BAG READY INDICATOR L (MONITOR) TO SAFING SENSOR	PURPLE-ORANGE
613	AIR BAG DIAGNOSTIC MODULE TO SAFING SENSOR (GROUND)	DK BLUE-WHITE
614	AIR BAG SAFING SENSORS TO INFLATORS	GRAY-ORANGE
615	AIR BAG DIAGNOSTIC MODULE TO DRIVER INFLATOR	GRAY-WHITE
616	AIR BAG DIAGNOSTIC MODULE TO PASSENGER INFLATOR	PINK-BLACK
617	AIR BAG DIAGNOSTIC MODULE (DEPLOY) TO RH SENSOR	PINK-ORANGE
618	AIR BAG DIAGNOSTIC MODULE (MONITOR) TO RH SENSOR	PURPLE-LT GREEN
619	AIR BAG DIAGNOSTIC MODULE (DEPLOY) TO CENTER SENSOR	PINK-WHITE
620	AIR BAG DIAGNOSTIC MODULE (MONITOR) TO CENTER SENSOR	PURPLE-LT BLUE
621	AIR BAG DIAGNOSTIC MODULE (DEPLOY) TO LH SENSOR	WHITE-YELLOW
622	AIR BAG DIAGNOSTIC MODULE (MONITOR) TO LH SENSOR	TAN-BLACK
623	AIR BAG DIAGNOSTIC MODULE (MONITOR) TO SAFING SENSOR	PURPLE-WHITE
624	DCP MODULE TO HEATED BACKLITE RELAY	LT BLUE-ORANGE
625	DCP MODULE TO PARKLAMP RELAY	LT BLUE-WHITE
626	OPEN DOOR WARNING LAMP FEED	PINK-YELLOW
627	OPEN DOOR WARNING LAMP TO OPEN DOOR WARNING SWITCH	BLACK-ORANGE
628	DOOR WIRE	WHITE
629	DOOR WIRE	BLACK
630	DOOR WIRE	RED
631	DOOR WIRE	YELLOW
632	DCP MODULE TO HEADLAMP RELAY	PINK-YELLOW
633	STEERING RATE SENSOR TERMINAL A CONTROL MODULE	RED
634	STEERING RATE SENSOR TERMINAL B CONTROL MODULE	BROWN
635	AIR SUSPENSION DIODE SWITCH TO CONTROL MODULE	YELLOW
636	BRAKE PRESSURE SWITCH TO CONTROL MODULE	ORANGE
637	AIR SUSPENSION CONTROL SIGNAL	LT GREEN
638	RIGHT FRONT SHOCK DAMPENING RELAY TO CONTROL MODULE	PURPLE
639	HIGH ELECTRO DRIVE FAN	PINK
640	WARNING LAMPS FEED	RED-YELLOW
641	LEFT FRONT SHOCK DAMPENING RELAY TO CONTROL MODULE	LT BLUE
642	WATER TEMP. WARNING LAMP TO WATER TEMP. SW. (COLD)	WHITE-LT GREEN
643	DIESEL WATER IN FUEL SENDER TO WARNING LAMP	RED
644	DIESEL TACH GROUND TO TACH GAGE MODULE	BLACK-YELLOW
645	SPEAKER VOICE COIL FEED RIGHT REAR CHANNEL AMP INPUT	PINK-BLACK
646	SPEAKER VOICE COIL FEED LEFT REAR CHANNEL AMP INPUT	PINK-YELLOW
647	WATER TEMP. WARNING LAMP TO WATER TEMP. SW. (HOT)	RED-BLACK
648	TACHOMETER FEED	RED-LT BLUE
649	SPEAKER VOICE COIL FEED LEFT FRONT CHANNEL AMP INPUT	ORANGE
650	RIGHT REAR SHOCK DAMPENING RELAY TO CONTROL MODULE	WHITE
651	LEFT REAR SHOCK DAMPENING RELAY TO CONTROL MODULE	DK GREEN
652	SHOCK DAMPENING RELAY HARD TO SHOCK DAMPENING CONTROL	PINK-BLACK
653	SHOCK DAMPENING RELAY SOFT TO SHOCK DAMPENING CONTROL	DK BLUE
654	ALT. SHUNT TO AMMETER	YELLOW-LT GREEN
655	STARTING MOTOR RELAY SHUNT TO AMMETER	RED-ORANGE
656	REDUNDANT MODULE TO ENGINE WARNING LAMP	PURPLE
657	EEC MODULE TO MALFUNCTION INDICATOR LITE	TAN
658	EEC MODULE TO CHECK ENGINE INDICATOR LAMP	PINK-LT GREEN
659	MODULE TO DOWN SWITCH	WHITE-LT BLUE
660	AIR COND. CONTROL SW. TO FRESH-AIR RECIRC. DOOR SOLENOID	YELLOW-LT GREEN
661	MODULE TO OVERRIDE SWITCH	LT GREEN-WHITE
662	MODULE TO MOTOR FEED	WHITE-BLACK
663	MODULE TO MOTOR FEED	LT GREEN-YELLOW
664	MODULE TO RELEASE SOLENOID	YELLOW-LT GREEN
665	OVERRIDE SWITCH TO LATCH	ORANGE-YELLOW
666	BATTERY FEED CAMPER	RED
667	LAMP RELAY TO MARKER LAMPS	WHITE-RED
668	INTERMINAL STARTER MOTOR RELAY TO INERTIA SWITCH	ORANGE-LT BLUE
669	OIL PRESSURE SWITCH TO CUTOUT RELAY	YELLOW
670	INERTIA SWITCH TO FUEL TANK SELECTOR SWITCH	RED
671	FUEL TANK SELECTOR SWITCH TO AFT FUEL PUMP	LT BLUE-YELLOW
672	FUEL TANK SELECTOR SWITCH TO MIDSHIP FUEL PUMP	LT GREEN-YELLOW
673	SELECTOR SWITCH TO MIDSHIP TANK	DK BLUE-YELLOW
674	SELECTOR SWITCH TO AUX. FUEL SOLENOID	BROWN-WHITE
675	SELECTOR SWITCH TO AFT AXLE TANK	YELLOW-LT BLUE
676	EEC MODULE TO SPEED CONTROL GROUND	RED
677	ANTI-SKID MODULE TO ANTI-SKID CONTROL VALVE	LT BLUE
678	ANTI-LOCK MODULE TO ANTI-LOCK CONTROL VALVE	YELLOW
679	SPEED CONTROL SENSE EEC MODULE TO SENSOR	GRAY-BLACK

CIRCUIT	DESCRIPTION *	COLOR
681	HEATED WINDSHIELD TRIGGER CIRCUIT SW. TO MODULE	TAN-RED
682	TEMP WARNING LAMP TO SENDING UNIT	GRAY-RED
683	SPEED CONTROL SENSE EEC MODULE TO CLUSTER	PURPLE-LT BLUE
684	COMPASS SENSOR FEED	PINK-BLACK
685	ANTI-LOCK MODULE TO ANTI-LOCK CONTROL VALVE	BLACK-WHITE
686	HEAD LP TIME DELAY CONTROL RELAY TO CIR. BREAKER	GRAY-ORANGE
687	ACC FEED	GRAY-YELLOW
688	HTD BACKLITE SW. TO TIME DELAY RELAY	GRAY-LT BLUE
689	LOGIC MODE	OK BLUE
690	RIGHT CHANNEL SIGNAL	GRAY
691	MOONROOF RELAY TO MICRO SWITCH OPEN	DK BLUE
692	MOONROOF RELAY TO MICRO SWITCH CLOSED	RED
693	MODULE DIAGNOSTIC	ORANGE
694	AMPLIFIER POWER RETURN	RED
695	MULTIPLEX WINDSHIELD WIPER OFF	BLACK-ORANGE
696	MULTIPLEX FARRING LAMPS	ORANGE-BLACK
697	MULTIPLEX HEADLAMPS	BROWN
698	MULTIPLEX WINDSHIELD WIPER OFF	RED
699	MULTIPLEX RELAY COIL FEED	ORANGE
700	MULTIPLEX WIPER RATE	YELLOW
701	C.B. SQUELCH POT	WHITE-PURPLE
702	C.B. PUSH TO TALK	WHITE-BLACK
703	C.B. DOWN SWITCH	WHITE-ORANGE
704	C.B. C-DIGIT	ORANGE
705	C.B. NOISE BLANKER	LT GREEN-ORANGE
706	C.B. SCAN I.E.D.	GRAY
707	C.B. UP SWITCH	WHITE-YELLOW
708	C.B. D-DIGIT	BROWN
709	C.B. VOLUME CONTROL	WHITE-LT BLUE
710	C.B. SCAN SWITCH	WHITE-LT GREEN
711	C.B. REGULATED 5V	LT GREEN-BLACK
712	C.B. A + DIGIT	PURPLE
713	C.B. MIC-AUDIO	WHITE
714	RELAY COIL FEED #2	PURPLE
715	C.B. A-DIGIT	LT GREEN
716	C.B. B-DIGIT	YELLOW
717	C.B. SPEAKER TO TRANSCEIVER	LT BLUE-RED
718	C.B. ON/OFF	RED-WHITE
719	WINDSHIELD WIPER HIGH	GRAY
720	C.B. B + DIGIT	LT BLUE
721	C.B. SPEAKER VOICE COIL RETURN	DK BLUE-LT GREEN
722	C.B. RELAY DRIVE	LT GREEN-RED
723	C.B. SPEAKER RELAY TO MIC	LT BLUE-ORANGE
724	C.B. C + DIGIT	LT GREEN-WHITE
725	RELAY COIL FEED #3	WHITE
726	WINDSHIELD WASHER	LT GREEN
727	REMOTE DEFROST	YELLOW-BLACK
728	RADIO SEEK	WHITE-ORANGE
729	RADIO MEMORY	RED-WHITE
730	CRT SCAN	LT BLUE-YELLOW
731	MULTIPLEX REVERSE DIMMING	WHITE-BLACK
732	MULTIPLEX LCD ILLUMINATION	BROWN-WHITE
733	MULTIPLEX SERVICE REMINDER RESET	PURPLE-WHITE
734	MULTIPLEX SERVICE REMINDER	TAN
735	MULTIPLEX MESSAGE 0	DK BLUE-WHITE
736	MULTIPLEX MESSAGE 1	PINK
737	TEMP SWITCH TO WARNING DEVICE	WHITE-LT BLUE
738	HEATED WINDSHIELD CONTROL TO HEATED WINDSHIELD SWITCH	YELLOW-WHITE
739	HEATED WINDSHIELD GROUND TEST LEAD	BLACK
740	VAC SWITCH TO VAC PUMP	ORANGE-LT BLUE
741	TIMER CONTROL VALVE TO CONTROL UNIT	LT BLUE-WHITE
742	RADIATOR COOLANT TEMP SWITCH TO CONTROL UNIT	LT BLUE-YELLOW
743	AIR TEMP SENSOR TO CONTROL UNIT	BLACK-LT BLUE
744	IDLE RPM SOLENOID TO CONTROL UNIT	TAN-WHITE
745	ANTENNA SWITCH TO POWER ANTENNA (UP)	RED-PINK
746	ANTENNA SWITCH TO POWER ANTENNA (DOWN)	DK GREEN-YELLOW
747	RADIO RECEIVER ASSY. TO FOOT CONTROL SWITCH	ORANGE-LT BLUE
748	BOOST SENSOR TO CONTROL UNIT	TAN
749	SENSOR AMPLIFY UNIT TO CONTROL UNIT #1	PINK-BLACK
750	SENSOR AMPLIFY UNIT TO CONTROL UNIT #2	GRAY-LT BLUE
751	BLOWER MOTOR SPEED CONTROLLER TO RESISTOR #3 (MED.)	DK BLUE-WHITE
752	BLOWER MOTOR SPEED CONTROLLER TO RESISTOR #2 (MED.)	YELLOW-RED
753	HEATER & A/C CONTROL SW. TO BLOWER RELAY SW.	YELLOW-RED
754	BLOWER MOTOR SPEED CONTROLLER TO RESISTOR #1 (MED.)	LT GREEN-WHITE
755	BLOWER MOTOR SWITCH RELAY TO RESISTOR (LOW SPEED)	BROWN-WHITE
756	HEATER & A/C CONTROL SW. (HI-NORM) TO RESISTOR (LOW RANGE)	RED-PINK
757	HEATER & A/C CONTROL SW. (HI-NORM) TO BLOWER MOTOR SW. RELAY	RED-WHITE
758	HEATER & A/C CONTROL SW (LO-HI-NORM) TO RESISTOR (LOW RANGE)	PURPLE-WHITE
759	SENSOR AMPLIFY UNIT TO CONTROL UNIT #3	DK GREEN-WHITE
760	SENSOR AMPLIFY UNIT TO CONTROL UNIT #4	WHITE-PURPLE
761	BLOWER MOTOR RELAY TO ENG. WATER TEMP. SWITCH (COLD)	WHITE-LT GREEN
762	ELECT SHIFT 4x4 MODULE TO MOTOR POSITION #1	YELLOW-WHITE
763	ELECT SHIFT 4x4 MODULE TO MOTOR POSITION #2	ORANGE-WHITE
764	ELECT SHIFT 4x4 MODULE TO MOTOR POSITION #3	BROWN-WHITE
765	HEATER & A/C CONTROL SW. TO REHEAT & A/C FEED	LT GREEN-YELLOW
766	HEATER & A/C CONTROL SW. (DE-FOG) TO INLET AIR CONTROL SOLENOID	RED-LT GREEN
767	AMBIENT SENSOR TO INST. PANEL THERMISTOR	LT BLUE-ORANGE
768	REFERENCE SENSOR TO HEAT DUCT THERMISTOR	LT GREEN-YELLOW
769	HATER & A/C CONTROL SW. (HI & LO NORM) TO BLOWER MOTOR SW. RELAY	LT BLUE-YELLOW
770	ELECT SHIFT 4x4 MODULE TO MOTOR POSITION #4	WHITE
771	ELECT SHIFT 4x4 MODULE TO MOTOR POSITION #5	PURPLE-YELLOW
772	ELECT SHIFT 4x4 MODULE TO SPEED SENSOR COIL	LT BLUE
773	HEATER & A/C CONTROL SW. (TEMP. SELECTOR) TO REHEAT AMPL.	DK GREEN-ORANGE
774	ELECT SHIFT 4x4 MODULE TO SPEED SENSOR RETURN	LT GREEN
775	HEATER & A/C CONTROL SW. (DEFOG) TO DEFROST CONT. SOLENOID	WHITE-PINK
776	CLIMATE CONTROL BOX TO HIGH BLOWER RELAY	ORANGE-BLACK
777	ELECT SHIFT 4x4 MODLUE TO MOTOR CONTROL COUNTER CLOCK WISE	YELLOW
778	ELECT SHIFT 4x4 MODULE TO MOTOR CONTROL	ORANGE
779	ELECT SHIFT 4x4 MODULE TO ELECT CLUTCH	BROWN
780	ELECT SHIFT MODULE TO 2H 4H SWITCH	DK BLUE
781	ELECT SHIFT TO 4L SWITCH	ORANGE-LT BLUE
782	ELECT SHIFT MODULE TO LOW RANGE INDICATOR LAMP ROOF CONSOLE	BROWN-WHITE
783	ELECT SHIFT MODULE TO GRAPHIC DISPLAY ROOF CONSOLE	GRAY
784	INDICATOR LAMP TO LOW RANGE SWITCH 4x4	LT BLUE-BLACK
785	BATTERY TO MULTIPLEX MODULE	BLACK-LT GREEN
786	FUEL TANK SELECTOR TO FUEL PUMP FRONT	RED
787	FUEL PUMP SAFETY SWITCH TO FUEL PUMP MOTOR	PINK-BLACK
789	FUEL TANK SELECTOR TO FUEL PUMP REAR	BROWN-WHITE
790	HEATER & A/C CONTROL SW. TO INST. PANEL THERMISTOR	WHITE-ORANGE
791	BATTERY TO MULTIPLEX SYSTEM	BLACK-WHITE
792	MULTIPLEX COMPUTER FEED	TAN-RED
793	LOW WASHER LEVEL TO SENSOR	YELLOW-BLACK
794	LOW COOLANT LEVEL RELAY TO SENSOR	LT BLUE
795	CAM SENSOR TO EEC MODULE	DK GREEN
796	CAM SENDER SIGNAL RETURN	LT BLUE
797	BATTERY FEED TO STEREO	LT GREEN-PURPLE
798	LEFT CHANNEL SIGNAL OUT	LT GREEN-RED
799	RIGHT CHANNEL SIGNAL OUT	ORANGE-BLACK
800	AMPLIFIER/SPEAKER SWITCH FEED TO LEFT REAR SPEAKER	GRAY-LT BLUE
801	AMPLIFIER/SPEAKER SWITCH GROUND TO LEFT REAR SPEAKER	PINK-LT BLUE
802	AMPLIFIER/SPEAKER SWITCH FEED TO RIGHT REAR SPEAKER	ORANGE-RED
803	AMPLIFIER/SPEAKER SWITCH GROUND TO RIGHT REAR SPEAKER	DK GREEN-ORANG"
804	SPEAKER VOICE COIL FEED - FRONT (LEFT CHANNEL)	ORANGE-LT GREEN
805	SPEAKER VOICE COIL FEED - FRONT (RIGHT CHANNEL)	WHITE-LT GREEN
806	SPEAKER VOICE COIL FEED - REAR (RIGHT CHANNEL)	PINK-LT BLUE
807	SPEAKER VOICE COIL FEED - REAR (LEFT CHANNEL)	PINK-LT GREEN
810	STOPLAMP SW. TO STOPLAMPS	RED-LT GREEN
811	SPEAKER SWITCH GROUND TO RIGHT FRONT SPEAKER	DK GREEN-ORANGE

* IN SOME CASES, THERE MAY BE ADDITIONAL CIRCUIT FUNCTIONS INCLUDED IN THE CIRCUIT DESCRIPTION LISTED.

STANDARD CIRCUIT CHART (BY NUMBER)

CIRCUIT	DESCRIPTION *	COLOR	CIRCUIT	DESCRIPTION *	COLOR
812	SPEAKER SWITCH FEED TO RIGHT FRONT SPEAKER	PINK-ORANGE	893	MEMORY MIRROR MODULE RH VERTICAL POSITION	LT BLUE-BLACK
813	SPEAKER SWITCH GROUND TO LEFT FRONT SPEAKER	LT BLUE-WHITE	894	MEMORY MIRROR MODULE POSITION	GRAY
814	SPEAKER SWITCH FEED TO LEFT FRONT SPEAKER	PINK-WHITE	895	MEMORY MIRROR MODULE	WHITE-PURPLE
815	AMPLIFIER SWITCH GROUND TO RIGHT FRONT SPEAKER	LT GREEN-ORANGE	896	MEMORY MIRROR MODULE LH HORIZONTAL POSITION	PINK-ORANGE
816	AMPLIFIER SWITCH FEED TO RIGHT FRONT SPEAKER	LT GREEN-PURPLE	897	MEMORY MIRROR MODULE TO LH VERTICAL DRIVE	TAN-BLACK
817	INDICATOR RELAY TO RH TURN LAMP	TAN-LT BLUE	898	MEMORY MIRROR MODULE TO LH HORIZONTAL DRIVER	TAN-RED
818	INDICATOR RELAY TO LH TURN LAMP	TAN-WHITE	899	MEMORY SEAT TO NEUTRAL SENSOR SWITCH	RED-WHITE
819	AMPLIFIER SWITCH GROUND TO LEFT FRONT SPEAKER	LT GREEN-WHITE	900	STARTER INTERRUPT RELAY TO NEUTRAL START SWITCH	WHITE-LT BLUE
820	AMPLIFIER SWITCH FEED TO LEFT FRONT SPEAKER	DK BLUE-YELLOW	901	AMPLIFIER 1D SPEED SENSOR RETURN	RED-LT BLUE
822	SPEAKER VOICE COIL FEED	BLACK-LT GREEN	902	TOP CONTROL RELAY TO MOTOR - UP	YELLOW
823	RADIO TO FADER CONTROL	LT GREEN	903	TOP CONTROL RELAY TO MOTOR - DOWN	RED
824	AMPLIFIER SWITCH GROUND TO RIGHT REAR SPEAKER	WHITE-PURPLE	904	(COIL) OR (ACCY) TERM OF IGNITION SWITCH TO ALTERNATOR REGULATOR (IGN. TERM)	LT GREEN-RED
825	AMPLIFIER SWITCH FEED TO RIGHT REAR SPEAKER	TAN-LT GREEN			
826	AMPLIFIER SWITCH GROUND TO LEFT REAR SPEAKER	DK BLUE-ORANGE	905	VEHICLE MAINTENANCE MONITOR MODULE TO OIL TEMP INPUT	LT BLUE
827	AMPLIFIER SWITCH FEED TO LEFT REAR SPEAKER	TAN-WHITE			
828	POWER FEED-SWITCH TO REAR AMPLIFIER	PURPLE-LT BLUE	906	VEHICLE MAINTENANCE MONITOR MODULE TO OIL TEMP OUTPUT	WHITE-LT BLUE
829	POWER FEED-SWITCH TO FRONT AMPLIFIER	WHITE-PURPLE			
830	SWITCH TO FADER RIGHT CHANNEL FEED	PINK-YELLOW	907	VEHICLE MAINTENANCE MONITOR MODULE TO ELEC. INSTR. CLUST. SENSE	PURPLE-LT GREEN
831	SWITCH TO FADER LEFT CHANNEL FEED	TAN			
832	MODE SELECT SWITCH FEED	BROWN-LT GREEN	908	VEHICLE MAINTENANCE MONITOR MODULE TO ENGINE STRAP	TAN-BLACK
833	MODE SELECT SWITCH LAMP	RED-BLACK			
834	ELECTRONIC SHOCK SENSOR A	RED-YELLOW	909	VEHICLE MAINTENANCE MONITOR MODULE TO SPEED SENSOR	LT BLUE-WHITE
835	ELECTRONIC SHOCK SENSOR B	RED-WHITE			
836	ACCELERATE DECELERATE SENSOR	ORANGE-WHITE	910	FUSED ACCY FEED - TRIPMINDER	BLACK-WHITE
837	ACCELERATE DECELERATE SENSOR RETURN	YELLOW-BLACK	911	OVERDRIVE CANCEL INDICATOR LAMP	LT GREEN-WHITE
838	ELECTRONIC SHOCK HARD CONTROL	LT GREEN-PURPLE	912	EEC MODULE TO TRANSMISSION	LT BLUE-WHITE
839	ELECTRONIC SHOCK SOFT CONTROL	LT GREEN-WHITE	913	LIFTGATE SW. TO LIFTGATE RELAY	GRAY-RED
840	ACTUATOR POSITION SENSOR LEFT FRONT	WHITE-BLACK	914	EEC MODULE - DATA PLUS	TAN-ORANGE
841	ACTUATOR POSITION SENSOR RIGHT FRONT	WHITE-RED	915	EEC MODULE - DATA MINUS	PINK-LT BLUE
842	ACTUATOR POSITION SENSOR LEFT REAR	WHITE-ORANGE	916	SPEED CONTROL VACUUM TO EEC MODULE	LT GREEN
843	ACTUATOR POSITION SENSOR RIGHT REAR	WHITE	917	VENT SWITCH TO BLOWER MOTOR - LO	PINK-LT GREEN
844	ELECTRONIC SHOCK DIAGNOSTIC	GRAY-RED	918	SEAT REG. SW. TO RECLINER MOTOR - UP	GRAY
845	ELECTRONIC SHOCK FEEDBACK ACTUATOR TO RELAY	TAN-BLACK	919	SEAT REG. SW. TO RECLINER MOTOR - DOWN	GRAY-BLACK
846	ELECTRONIC SHOCK METAL OXIDE VERISTOR	TAN-RED	920	HEATED WINDSHIELD LH TO SENSE RESISTOR	BROWN-WHITE
847	DECELERATION SENSOR	ORANGE-LT GREEN	921	FEED TO FUEL SHUTOFF LAMP	GRAY-ORANGE
848	PROCESSOR LOOP SIGNAL RETURN	DK GREEN-ORANGE	922	FUEL PUMP RESISTOR TO RELAY	WHITE-RED
849	DIGITAL AUDIO DISC LOGIC SENSOR	TAN-BLACK	923	TRANSMISSION OIL TEMP	ORANGE-BLACK
850	COIL "A" TO DISTRIBUTORLESS IGNITION MODULE	YELLOW-BLACK	924	COAST CLUTCH SOLENOID	BROWN
851	COIL "B" TO DISTRIBUTORLESS IGNITION MODULE	YELLOW-RED	925	ELECTRONIC THROTTLE VALVE POWER	YELLOW-WHITE
852	COIL "C" TO DISTRIBUTORLESS IGNITION MODULE	YELLOW-WHITE	926	EEC MODULE CONTROL OF HIGH SPEED FUEL PUMP	LT BLUE-ORANGE
853	HEATED WINDSHIELD FUSE RESISTOR	BROWN	927	EVO MODULE TO TEST CONNECTOR	ORANGE-BLACK
854	THIRD LOCKOUT SOLENOID	GRAY-WHITE	928	POWER FEED FROM AMPLIFIER	PURPLE
855	RIGHT REAR AIR INPUT RETURN	LT BLUE	929	EEC MODULE TO SPARK ADVANCE	PINK
856	LEFT CHANNEL SIGNAL	PURPLE			
857	LEFT FRONT AIR INPUT RETURN	WHITE-ORANGE	930	PROGRAMMABLE RIDE CONTROL MODULE TO STAR TEST CONNECTOR	DK BLUE
858	RIGHT FRONT AIR INPUT RETURN	BROWN			
859	LEFT REAR AIR INPUT RETURN	YELLOW	931	BATTERY FEED TO RELAY CONTROLLER	ORANGE
860	LEFT MOTOR-DRIVER - F	PURPLE-YELLOW	932	DAYTIME RUNNING LAMP	GRAY-WHITE
861	LEFT MOTOR-DRIVER - R	BLACK-WHITE	933	ESC SWITCH TO ESC VALVE CONTROL	LT GREEN-BLACK
862	LEFT LIMIT-A - DRIVER	BROWN-YELLOW	934	EMISSION SPEED SENSOR TO MODULATOR CONTROL	TAN-WHITE
863	RIGHT DOOR OPEN - PASSENGER	RED	935	HEATED WINDSHIELD TO FUSE	DK BLUE-YELLOW
864	RIGHT MOTOR-PASSENGER - F	ORANGE	936	KEY CYLINDER SENSOR TO ANTI-THEFT MODULE	DK GREEN-WHITE
865	RIGHT MOTOR-PASSENGER - R	PURPLE-WHITE	939	MODULATOR TO THERMO. SWITCH	TAN-BLACK
866	INERTIA SWITCH TO MODULE	WHITE	941	WASHER PUMP MOTOR FEED	BLACK-WHITE
867	LEFT DOOR OPEN - DRIVER	DK BLUE	946	REAR WASHER PUMP FEED	PURPLE-LT GREEN
868	EMERGENCY RELEASE LEVERS	GRAY-RED	950	WASHER CONTROL SWITCH FEED	WHITE-BLACK
869	RETARD VALVE TO CONTROL RELAY TERM. #1	LT GREEN-YELLOW	955	W/S WIPER MOTOR ARM RH TO W/S WIPER SWITCH	RED-ORANGE
871	SEAT BELT INDICATOR LAMP TO MODULE	YELLOW	956	W/W WIPER SWITCH TO W/S WIPER MOTOR FIELD RH	LT GREEN-ORANGE
872	LEFT LIMIT-B - DRIVER	LT GREEN	965	SUPERCHARGER SOLENOID #1	LT GREEN-PURPLE
873	RIGHT LIMIT-B - PASSENGER	TAN	966	SUPERCHARGER SOLENOID #2	RED-YELLOW
874	RIGHT LIMIT-A - PASSENGER	GRAY	967	MASS AIR FLOW	DK BLUE-ORANGE
875	GROUND LOGIC MODULE	BLACK-LT BLUE	968	MASS AIR FLOW RETURN	TAN-LT BLUE
876	VENT SWITCH TO RIGHT FRONT VENT - CONSOLE	BLACK-ORANGE	969	MASS AIR FLOW GROUND	BLACK
877	RELEASE LEVER WARN INDICATOR LAMP - CONSOLE	WHITE-ORANGE			
878	VENT SWITCH TO RIGHT FRONT VENT MOTOR	BLACK-LT BLUE	973	BATTERY FEED TO AUX. FUEL SELECTOR SWITCH	RED
879	VENT CROSSOVER FEED	RED-BLACK	974	FUEL CONTROL SWITCH TO FUEL CONTROL VALVE	ORANGE
880	VENT CROSSOVER FEED	RED-LT BLUE	977	BRAKE WARNING SWITCH TO INDICATOR LAMP	PURPLE-WHITE
881	WINDOW SWITCH TO RIGHT REAR MOTOR	BROWN	978	SEAT REGULATOR SWITCH TO FRONT MOTOR (LH)	YELLOW-LT BLUE
882	WINDOW SWITCH TO RIGHT REAR MOTOR	BROWN-YELLOW	979	SEAT REGULATOR SWITCH TO FRONT MOTOR (LH)	RED-LT BLUE
883	AIR COND. CONTROL RELAY FEED	PINK-LT BLUE	980	SEAT REGULATOR SWITCH TO HORZ. MOTOR (LH)	YELLOW-WHITE
884	WINDOW SWITCH TO LEFT REAR MOTOR	YELLOW-BLACK	981	SEAT REGULATOR SWITCH TO HORZ. MOTOR (LH)	RED-WHITE
885	WINDOW SWITCH TO LEFT REAR MOTOR	YELLOW-LT BLUE	982	SEAT REGULATOR SWITCH TO REAR MOTOR (LH)	YELLOW-LT GREEN
886	VENT SWITCH TO LEFT FRONT VENT MOTOR	ORANGE-WHITE	983	SEAT REGULATOR SWITCH TO REAR MOTOR (LH)	RED-LT GREEN
887	VENT SWITCH TO LEFT FRONT VENT MOTOR	YELLOW	984	SEAT REGULATOR SWITCH TO FRONT MOTOR (RH)	YELLOW-LT BLUE
888	MEMORY MIRROR MODULE TO RH HORIZONTAL DRIVER	LT BLUE	985	SEAT REGULATOR SWITCH TO FRONT MOTOR (RH)	RED-LT BLUE
889	MEMORY MIRROR MODULE MOTOR DIRECTION	BLACK-ORANGE	986	SEAT REGULATOR SWITCH TO FRONT MOTOR (RH)	YELLOW-WHITE
890	MEMORY MIRROR MODULE TO RH VERTICAL DRIVE	BROWN-WHITE	987	SEAT REGULATOR SWITCH TO HORZ. MOTOR (RH)	RED-WHITE
891	MEMORY MIRROR MODULE POSITION +	RED-BLACK	988	SEAT REGUALTOR SWITCH TO REAR MOTOR (RH)	YELLOW-LT GREEN
892	MEMORY MIRROR MODULE RH HORIZONTAL POSITION	ORANGE	989	SEAT REGULATOR SWITCH TO REAR MOTOR (RH)	RED-LT GREEN
			990	SEAT REGULATOR SWITCH TO FRONT MOTOR (LH)	YELLOW-LT BLUE
			993	INTERMITTENT GOVERNOR TO WINDSHIELD WIPER SWITCH	BROWN-WHITE

* IN SOME CASES, THERE MAY BE ADDITIONAL CIRCUIT FUNCTIONS INCLUDED IN THE CIRCUIT DESCRIPTION LISTED.

STANDARD CIRCUIT CHART (BY COLOR)

COLOR	DESCRIPTION *	CIRCUIT	COLOR	DESCRIPTION *	CIRCUIT
(COLOR OPT.)	BLIND CIRCUIT TERM. IN HARNESS CANNOT BE CHECKED FOR CONT.	48	BROWN-YELLOW	DCP MODULE TO WASHER RELAY	591
BLACK	GROUND CIRCUIT	57	BROWN-YELLOW	FUEL INJECTOR #3 CYLINDER	557
BLACK	MARKER LAMP SWITCH TO MARKER LAMPS	207	BROWN-YELLOW	ELECTRIC DRIVE COOLING FAN	228
BLACK	16 GA FUSE LINK	291	BROWN-YELLOW	MAP LAMP SWITCH TO RH MAP LAMP	125
BLACK	HEATED WINDSHIELD GROUND TEST LEAD	739	BROWN-YELLOW	EMISSION CONTROL VALVE TO SWITCH	81
BLACK	DOOR WIRE	629	DK BLUE	BATTERY TO HI-BEAM	62
BLACK	DCP MODULE SIGNAL GROUND TO RADIO	596	DK BLUE	HORN SWITCH CONTROL	1
BLACK	MASS AIR FLOW GROUND	969	DK BLUE	20 GA FUSE LINK	302
BLACK	ELECTRONIC CLUSTER FROM GROUND IN KEYBOARD	373	DK BLUE	L.H. REMOTE MIRROR MOTOR FEED-C.C.W.	541
BLACK-LT BLUE	DOOR AJAR SWITCH TO INDICATOR LAMP LEFT REAR GROUND	363	DK BLUE	FEED TO FAILURE SWITCH	600
BLACK-LT BLUE	DIESEL CONTROL MODULE GROUND RETURN	488	DK BLUE	ELECT SHIFT MODULE TO 2H 4H SWITCH	780
BLACK-LT BLUE	AIR TEMP SENSOR TO CONTROL UNIT	743	DK BLUE	MOONROOF RELAY TO MICRO SWITCH OPEN	691
BLACK-LT BLUE	VENT SWITCH TO RIGHT FRONT VENT MOTOR	878	DK BLUE	SHOCK DAMPENING RELAY SOFT TO SHOCK DAMPENING CONTROL	653
BLACK-LT BLUE	GROUND LOGIC MODULE	875	DK BLUE	LOGIC MODE	689
BLACK-LT BLUE	COURTESY LAMP SWITCH TO COURTESY LAMP	53	DK BLUE	PROGRAMMABLE RIDE CONTROL MODULE TO STAR TEST CONNECTOR	930
BLACK-LT BLUE	WARNING LAMP PROVE OUT	41	DK BLUE	LEFT DOOR OPEN - DRIVER	867
BLACK-LT BLUE	COURTESY LAMP SW. TO "C" PILLAR LAMPS	127	DK BLUE	CRANKSHAFT POSITION SENSOR FEED	349
BLACK-LT GREEN	KEYLESS DOOR LOCK ILLUMINATION GROUND TO MODULE	76	DK BLUE-LT GREEN	WARNING LAMP TO ANTI-THEFT MODULE	343
BLACK-LT GREEN	CONSTANT VOLTAGE UNIT TO GAUGE	60	DK BLUE-LT GREEN	BAROMETRIC PRESSURE SENSOR FEED	356
BLACK-LT GREEN	CONSTANT VOLTAGE UNIT AND INDICATOR LAMPS FEED	30	DK BLUE-LT GREEN	C.B. SPEAKER VOICE COIL RETURN	721
BLACK-LT GREEN	ACCY FEED FROM IGNITION SWITCH	297	DK BLUE-LT GREEN	HEATER & A/C CONTROL SW. (LO-NORM) TO CLIMATE CONTROL UNIT	249
BLACK-LT GREEN	COLD START INJECTOR	230	DK BLUE-LT GREEN	BUFFER FUEL LEVEL OUTPUT TO TRIPMINDER	205
BLACK-LT GREEN	BATTERY TO MULTIPLEX MODULE	785	DK BLUE-LT GREEN	THERMOCOUPLE POS TO EXHAUST SYST. OVERTEMP PROTECT MODULE	90
BLACK-LT GREEN	BLOWER MOTOR RELAY (LOAD TERM) TO BLOWER MOTOR	536	DK BLUE-ORANGE	ANTI-THEFT SWITCH ARM	24
BLACK-LT GREEN	SPEAKER VOICE COIL FEED	822	DK BLUE-ORANGE	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	56
BLACK-LT GREEN	BLOWER MOTOR RELAY FEED	364	DK BLUE-ORANGE	AUTOLAMP AMPLIFIER TO RHEOSTAT	217
BLACK-LT GREEN	POWER RELAY TO GLOW PLUGS (RIGHT BANK)	336	DK BLUE-ORANGE	HEADLAMP FLASH TO PASS SWITCH FEED	196
BLACK-ORANGE	FUEL 1 GROUND TO TACH/GAUGE MODULE	396	DK BLUE-ORANGE	AMPLIFIER SWITCH GROUND TO LEFT REAR SPEAKER	826
BLACK-ORANGE	REMOTE CONVENIENCE SELF DIAGNOSTIC GROUND	571	DK BLUE-ORANGE	MASS AIR FLOW	967
BLACK-ORANGE	HEATED WINDSHIELD CONTROL TO ELECT ALTERNATOR REGULATOR	579	DK BLUE-ORANGE	CRANK ENABLE TO IGNITION MODULE	325
BLACK-ORANGE	CENTER REAR TAILLAMP BULB OUTAGE	573	DK BLUE-WHITE	R.F. DOOR UNLOCK SWITCH TO L.F. DOOR UNLOCK SWITCH	390
BLACK-ORANGE	OPEN DOOR WARNING LAMP TO OPEN DOOR WARNING SWITCH	627	DK BLUE-WHITE	BLOWER MOTOR SPEED CONTROLLER TO RESISTOR #3 (MED.)	751
BLACK-ORANGE	MULTIPLEX WINDSHIELD WIPER OFF	695	DK BLUE-WHITE	MULTIPLEX MESSAGE O	735
BLACK-ORANGE	VENT SWITCH TO RIGHT FRONT VENT-CONSOLE	876	DK BLUE-WHITE	INTERMITTENT GOVERNOR TO W/S WIPER SWITCH	590
BLACK-ORANGE	MEMORY MIRROR MODULE MOTOR DIRECTION	889	DK BLUE-WHITE	AIR BAG DIAGNOSTIC MODULE SAFING SENSOR (GROUND)	613
BLACK-ORANGE	ELEC. ENG. CONTROL MOD. TO THICK FILM IGN. MOD.	259	DK BLUE-WHITE	FUSE HOLDER TO HEADLAMP DIMMER AMPLIFIER	504
BLACK-ORANGE	MEMORY SEAT SWITCH POSITION #2	268	DK BLUE-WHITE	THERMOMETER AMBIENT SENSOR RETURN	234
BLACK-ORANGE	DIESEL WATER IN FUEL SENDER TO WARNING LAMP GROUND	327	DK BLUE-WHITE	SEAT BELT WARNING TIMER TO R.F. SEAT SENSOR	86
BLACK-ORANGE	POWER SUPPLY TO BATTERY	38	DK BLUE-WHITE	ELECTRONIC CONTROL UNIT TO SOLENOID ACTUATOR	77
BLACK-ORANGE	ENGINE COMPARTMENT LAMP FEED	80	DK BLUE-YELLOW	DEFOGGER SW. TO DEFOGGER MOTOR	191
BLACK-ORANGE	COURTESY LAMP SW. TO INSTR. PANEL COURTESY LAMP	126	DK BLUE-YELLOW	THERMOMETER SENSOR FEED	233
BLACK-PINK	KEY WARNING SWITCH TO BUZZER	158	DK BLUE-YELLOW	SELECTOR SWITCH TO MIDSHIP TANK	673
BLACK-PINK	BACKUP LAMP	140	DK BLUE-YELLOW	AMPLIFIER SWITCH FEED TO LEFT FRONT SPEAKER	820
BLACK-PINK	CARGO LAMP SW. TO CARGO LAMP	55	DK BLUE-YELLOW	HEATED WINDSHIELD TO FUSE	935
BLACK-PINK	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	28	DK BLUE-YELLOW	AIR COMPRESSOR POWER RELAY CONTROL	420
BLACK-PINK	ECU TO VACUUM SWITCH 4	211	DK GREEN	REARVIEW OUTSIDE MIRROR DOWN	411
BLACK-PINK	AIR SUSPENSION ELECTRONICS GROUND	432	DK GREEN	EGR VALVE TO EEC MODULE	360
BLACK-PINK	HCU (MAIN) TO MODULE	493	DK GREEN	CAM SENSOR TO EEC MODULE	795
BLACK-PINK	MODULE TO LIGHT	464	DK GREEN	STOPLAMP SWITCH TO HI MOUNT STOPLAMP	569
BLACK-PINK	DOOR AJAR SWITCH TO INDICATOR LAMP RIGHT FRONT GROUND	345	DK GREEN	REAR LAMP TO TRAILER RELAY FEED	576
BLACK-WHITE	DOOR AJAR SWITCH TO INDICATOR LAMP RIGHT REAR GROUND	346	DK GREEN	R.H. REMOTE MIRROR MOTOR FEED-C.W.	543
BLACK-WHITE	SENSOR SIGNAL RETURN	359	DK GREEN	LEFT REAR SHOCK DAMPENING RELAY TO CONTROL MODULE	651
BLACK-WHITE	SIGNAL GROUND TO TACH/GAUGE MODULE	397	DK GREEN	FAILURE WARNING LIGHT	603
BLACK-WHITE	LEFT MOTOR-DRIVER - R	861	DK GREEN	14 GA FUSE LINK	299
BLACK-WHITE	ANTI-LOCK MODULE TO ANTI-LOCK CONTROL VALVE	685	DK GREEN	TRAILER RH TURN SIGNAL	64
BLACK-WHITE	BATTERY TO MULTIPLEX SYSTEM	791	DK GREEN	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	65
BLACK-WHITE	WINDSHIELD WIPER INTERMITTENT GOVERNOR FEED	587	DK GREEN	SUPPLEMENTAL ALTERNATOR STATOR C TERM. TO WINDSHIELD	72
BLACK-WHITE	DEDICATED GROUND	570	DK GREEN	CLOCK ADVANCE SWITCH TO MESSAGE CENTER	141
BLACK-WHITE	SPEED SIGNAL SPEEDO TACH MODULE TO FUEL COMPUTER	565	DK GREEN-LT GREEN	ELECTRONIC CONTROL UNIT TO ENGINE VACUUM SWITCH	75
BLACK-WHITE	CIRCUIT BREAKER (LOAD TERM) TO CONTROL SWITCH (BATT. TERM)	517	DK GREEN-LT GREEN	EMA CONTROL TO SPARK RETARD SWITCH	21
BLACK-WHITE	CORNERING LAMP SWITCH FEED	526	DK GREEN-LT GREEN	THROTTLE ANGLE POSITION SENSOR FEED	355
BLACK-WHITE	WASHER PUMP MOTOR FEED	941	DK GREEN-LT GREEN	AIR SUSPENSION MALFUNCTION WARNING LAMP	419
BLACK-WHITE	FUSED ACCY FEED - TRIPMINDER	910	DK GREEN-LT GREEN	R.F. DOOR LOCK SWITCH TO L.F. DOOR LOCK SWITCH	389
BLACK-WHITE	CIRCUIT BREAKER TO SEAT LATCH RELAY	171	DK GREEN-LT GREEN	SEAT BELT WARNING INDICATOR LAMP FEED	450
BLACK-WHITE	SPEAKER VOICE COIL RETURN	287	DK GREEN-ORANGE	HEATER & A/C CONTROL SW. (TEMP. SELECTOR) TO REHEAT AMPL.	773
BLACK-WHITE	SEAT REG. CONTROL SWITCH FEED	51	DK GREEN-ORANGE	SPEAKER SWITCH GROUND TO RIGHT FRONT SPEAKER	811
BLACK-WHITE	INSTRUMENT PANEL LAMP SWITCH FEED	88	DK GREEN-ORANGE	AMPLIFIER/SPEAKER SWITCH GROUND TO RIGHT REAR SPEAKER	803
BLACK-YELLOW	WARNING LAMP TO LIGHTS ON RELAY	111	DK GREEN-ORANGE	PROCESSOR LOOP SIGNAL RETURN	848
BLACK-YELLOW	WARNING LAMP RELAY FEED	112	DK GREEN-ORANGE	MCU MODULE TO KNOCK SENSOR	311
BLACK-YELLOW	ACCESSORY FEED TO MESSAGE CENTER	231	DK GREEN-ORANGE	PARITY BIT-DISPLAY TO MESSAGE CENTER	178
BLACK-YELLOW	EFE CARBURETOR SPACE FEED	229	DK GREEN-PURPLE	TRANSMISSION THROTTLE VALVE SOLENOID 2	315
BLACK-YELLOW	RELAY FEED	175	DK GREEN-PURPLE	ANTI-THEFT SWITCH DISARM	25
BLACK-YELLOW	INJECTION PUMP FUEL TEMPERATURE SENSOR	225	DK GREEN-PURPLE	HEATED EXTERIOR MIRROR FEED	59
BLACK-YELLOW	AIR BAG DIAGNOSTIC MODULE TO RELAY INDICATOR LAMP	608	DK GREEN-PURPLE	DATA-MESSAGE CENTER TO DISPLAY	174
BLACK-YELLOW	DIESEL TACH GROUND TO TACH GAGE MODULE	644	DK GREEN-PURPLE	AIR FUEL SENSOR TO E.C.U	94
BLACK-YELLOW	TACHOMETER GROUND TO TACH/GAUGE MODULE	398	DK GREEN-PURPLE	POWER FEED DECEL TIMER TO THROTTLE KICKER	584
BLACK-YELLOW	DOOR AJAR SWITCH TO INDICATOR LAMP LEFT FRONT GROUND	344	DK GREEN-WHITE	SENSOR AMPLIFY UNIT TO CONTROL UNIT #3	759
BLACK-YELLOW	COMPRESSOR CLUTCH FEED	347	DK GREEN-WHITE	KEY CYLINDER SENSOR TO ANTI-THEFT MODULE	936
BROWN	DOOR AJAR RELAY TO DOOR SWITCH	374	DK GREEN-WHITE	STOPLAMP SW. TO STOPLAMP RELAY (COIL TERM.)	475
BROWN	POWER "THIGH" BOLSTER DOWN	492	DK GREEN-WHITE	FUEL LEVEL RECEIVER TO FUEL LEVEL WARNING RELAY (REG. TERM.)	367
BROWN	STEERING RATE SENSOR TERMINAL B CONTROL MODULE	634	DK GREEN-WHITE	SENSOR SIGNAL TO AMPLIFIER	150
BROWN	FUEL SIGNAL TACH MODULE TO FUEL COMPUTER	564	DK GREEN-WHITE	OIL PRESSURE SWITCH TO TIMER	254
BROWN	HEATED WINDSHIELD CONTROL TO ALT POWER RELAY	580	DK GREEN-YELLOW	HEADLAMP SWITCH TO AUTOLAMP AMPLIFIER	219
BROWN	ELECT SHIFT 4 x 4 MODULE TO ELECT CLUTCH	779	DK GREEN-YELLOW	ELECTRONIC CONTROL UNIT TO EXHAUST GAS OXYGEN SENSOR	74
BROWN	MULTIPLEX HEADLAMPS	697	DK GREEN-YELLOW	ELECTRONIC SWITCH TO IGNITION COIL NEG. TERMINAL	11
BROWN	C.B. D-DIGIT	708	DK GREEN-YELLOW	AIR SUSPENSION CONTROL MODULE FEED	418
BROWN	COAST CLUTCH SOLENOID	924	DK GREEN-YELLOW	ANTENNA SWITCH TO POWER ANTENNA (DOWN)	746
BROWN	EATC LH SUNLOAD SENSOR POSITIVE	468	DK GREEN-YELLOW	SPLICE #3 TO POWER RELAY	546
BROWN	WINDOW SWITCH TO RIGHT REAR MOTOR	881	DL BLUE	TRAILER STOP LAMPS	43
BROWN	HEATED WINDSHIELD FUSE RESISTOR	853	GRAY	LOW OIL LEVEL RELAY TO WARNING LAMP	208
BROWN	RIGHT FRONT AIR INPUT RETURN	858	GRAY	12 GA FUSE LINK	290
BROWN	TO ELECTRONIC CLUSTER FROM ENGLISH/METRIC SWITCH IN KEYBOARD	273	GRAY	HEADLAMP DIMMER RELAY TO HEADLAMP DIMMER SWITCH	502
BROWN	FEEDBACK CARBURETOR COIL "A"	304	GRAY	ELECT SHIFT MODULE TO GRAPHIC DISPLAY ROOF CONSOLE	783
BROWN	SWITCH FEED	276	GRAY	C.B. SCAN L.E.D.	706
BROWN	18 GA FUSE LINK	292	GRAY	WINDSHIELD WIPER HIGH	719
BROWN	KEYLESS DOOR LOCK SWITCH ENABLE FROM MODULE	124	GRAY	RIGHT CHANNEL SIGNAL	690
BROWN	HEADLAMP SWITCH TO TAIL LAMPS & SIDE MARKER LAMPS	14	GRAY	SEAT REG. SW. TO RECLINER MOTOR-UP	918
BROWN-LT BLUE	DOOR JAMB SWITCH TO LIGHTS ON RELAY	138	GRAY	RIGHT LIMIT-A- PASSENGER	874
BROWN-LT BLUE	LH HEADLAMP BULB OUTAGE	108	GRAY	MEMORY MIRROR MODULE POSITION	894
BROWN-LT BLUE	SEAT BELT WARNING TIMER TO L.F. RETRACTOR SWITCH	85	GRAY	AIR SUSPENSION SYSTEM GROUND	430
BROWN-LT BLUE	FUEL METERING CONTROL LEVER ACTUATOR 1 MINUS	232	GRAY	EATC RH SUNLOAD SENSOR NEGATIVE	483
BROWN-LT BLUE	DEFOGGER SW. TO DEFOGGER MOTOR	186	GRAY	CRANKSHAFT SENSOR SIGNAL RETURN	350
BROWN-LT BLUE	FUEL INJECTOR #4 CYLINDER	558	GRAY	DIESEL CONTROL SWITCH TO POWER RELAY & LAMP CONTROL RELAY	339
BROWN-LT GREEN	DCP MODULE TO WIPER PARK OVER-RIDE RELAY	592	GRAY-BLACK	LIMIT SW. TO BACK WINDOW REG. MOTOR	401
BROWN-LT GREEN	MODE SELECT SWITCH FEED	832	GRAY-BLACK	FRONT TILT POSITION SENSE	441
BROWN-LT GREEN	EGR VALVE POSITION FEED	352	GRAY-BLACK	SEAT REG. SW. TO RECLINER MOTOR - DOWN	919
BROWN-LT GREEN	AUTOLAMP AMPLIFIER TO SENSOR	222	GRAY-BLACK	VALVE #5 TO MODULE	499
BROWN-LT GREEN	POWER SERVO TO CLIMATE CONTROL UNIT (AMP)	245	GRAY-BLACK	SPEED CONTROL SENSE EEC MODULE TO SENSOR	679
BROWN-LT GREEN	MEMORY SEAT SWITCH POSITION #1	267	GRAY-BLACK	WINDOW REGULATOR MOTOR TO GROUND	157
BROWN-LT GREEN	SERVO FEEDBACK POTENTIOMETER BASE TO AMPLIFIER	149	GRAY-BLACK	INSIDE DOOR HANDLE SWITCH TO RETRACTOR INHIBITOR MODULE	185
BROWN-ORANGE	VACUUM DOOR LOCK SWITCH TO SOLENOID (UNLOCK)	116	GRAY-BLACK	SERVO SOURCE VACUUM SOLENOID TO CONTROL TRANSISTOR	145
BROWN-ORANGE	MEMORY SEAT SWITCH SET	270	GRAY-LT BLUE	MILES/KILOMETERS SWITCH TO MESSAGE CENTER	161
BROWN-ORANGE	IGNITION SWITCH TO THERMACTOR TIMER	251	GRAY-LT BLUE	HTD BACKLITE SW. TO TIME DELAY RELAY	688
BROWN-ORANGE	BLOWER MOTOR FEED	181	GRAY-LT BLUE	SENSOR AMPLIFY UNIT TO CONTROL UNIT #2	750
BROWN-ORANGE	VACUUM SOLENOID TO TEMP. SW.	369	GRAY-LT BLUE	AMPLIFIER/SPEAKER SWITCH FEED TO LEFT REAR SPEAKER	800
BROWN-ORANGE	RADIO MEMORY SEEK	372	GRAY-LT BLUE	ANEROID SWITCH TO MCU MODULE	394
BROWN-ORANGE	RADIO SWITCH TO ANTENNA RELAY	449	GRAY-ORANGE	SPARK MODULE TO MCU MODULE	395
BROWN-PINK	AIR SUSPENSION HEIGHT SENSOR LO- R.F.	425	GRAY-ORANGE	HEAD LP TIME DELAY CONTROL RELAY TO CIR. BREAKER	686
BROWN-PINK	DIESEL CONTROL SWITCH TO LAMP CONTROL RELAY	338	GRAY-ORANGE	AIR BAG SAFING SENSORS TO INFLATORS	614
BROWN-PINK	IGNITION SWITCH ACCY TERM. TO DECK LID OPEN WARNING LAMP	485	GRAY-ORANGE	FEED TO FUEL SHUTOFF LAMP	921
BROWN-PINK	POWER RELAY COIL TO MODULE	513	GRAY-ORANGE	AVERAGE SPEED SWITCH TO MESSAGE CENTER	156
BROWN-PINK	STARTING MOTOR RELAY TO IGNITION COIL "I" TERM.	262	GRAY-ORANGE	ELECTRONIC CONTROL UNIT TO DECELERATION SOLENOID	47
BROWN-WHITE	THERMOSTAT SWITCH FEED	182	GRAY-RED	DISTANCE TO EMPTY SWITCH TO MESSAGE CENTER	155
BROWN-WHITE	HEADLAMP SWITCH TO ELECTRONIC CLUSTER DIMMING	192	GRAY-RED	THERMOCOUPLE 1 NEG. TO EXHAUST SYST. OVERTEMP PROTECT MODULE	91
BROWN-WHITE	FLUID WARNING SWITCH TO PRESSURE SWITCH	549	GRAY-RED	INHIBITOR MODULE TO RETRACTOR OVERRIDE SOLENOID	187
BROWN-WHITE	EXTENDED USEFUL LIFE SENSOR TO WARNING LAMP	574	GRAY-RED	EXHAUST BACK PRESSURE VALVE ACTUATOR	318
BROWN-WHITE	SELECTOR SWITCH TO AUX. FUEL SOLENOID	674	GRAY-RED	LIFTGATE SW. TO LIFTGATE RELAY	913
BROWN-WHITE	ELECT SHIFT 4 x 4 MODULE TO MOTOR POSITION #3	764	GRAY-RED	DIESEL COLD ADVANTAGE	607
BROWN-WHITE	ELECT SHIFT MODULE TO LOW RANGE INDICATOR LAMP ROOF CONSOLE	782	GRAY-RED	MOTOR TO MOTOR RELAY	538
BROWN-WHITE	MULTIPLEX LCD ILLUMINATION	732	GRAY-RED	TEMP WARNING LAMP TO SENDING UNIT	682
BROWN-WHITE	BLOWER MOTOR SWITCH RELAY TO RESISTOR (LOW SPEED)	755	GRAY-RED	ELECTRONIC SHOCK DIAGNOSTIC	844
BROWN-WHITE	FUEL TANK SELECTOR TO FUEL PUMP REAR	789	GRAY-RED	EMERGENCY RELEASE LEVERS	868
BROWN-WHITE	INTERMITTENT GOVERNOR TO WINDSHIELD WIPER SWITCH	993	GRAY-RED	SWITCH TO VALVE	455
BROWN-WHITE	HEATED WINDSHIELD LH TO SENSE RESISTOR	920	GRAY-RED	SEAT PROCESSOR ASSY TO FRONT MOTOR LH	452
BROWN-WHITE	DECK LID OPEN WARNING LAMP TO DECK LID OPEN SWITCH	486	GRAY-RED	WINDOW REG. SW. TO BACK WINDOW REG. MOTOR	402
BROWN-WHITE	MEMORY MIRROR MODULE TO RH VERTICAL DRIVE	890	GRAY-WHITE	WINDOW REG. SW. TO WINDOW REG. MOTOR	403
BROWN-WHITE	TURN SIGNAL SWITCH TO RH CORNERING LAMP	379	GRAY-WHITE	THIRD LOCKOUT SOLENOID	854
BROWN-WHITE	ELECT. ENG. CONTL. MOD. TO IDLE SPD. CONTL. MOTOR #3	376	GRAY-WHITE	AIR BAG DIAGNOSTIC MODULE TO DRIVER INFLATOR	615
BROWN-YELLOW	HEATER BLOWER SWITCH FEED	399	GRAY-WHITE	DAYTIME RUNNING LAMP	932
BROWN-YELLOW	LEFT LIMIT-A - DRIVER	862			
BROWN-YELLOW	WINDOW SWITCH TO RIGHT REAR MOTOR	882			
BROWN-YELLOW	EATC LH SUNLOAD SENSOR NEGATIVE	476			

* IN SOME CASES, THERE MAY BE ADDITIONAL CIRCUIT FUNCTIONS INCLUDED IN THE CIRCUIT DESCRIPTION LISTED.

STANDARD CIRCUIT CHART (BY COLOR)

COLOR	DESCRIPTION *	CIRCUIT
GRAY-WHITE	AIR CONDITIONER CLUTCH RELAY	321
GRAY-WHITE	DISTANCE SWITCH TO MESSAGE CENTER	164
GRAY-WHITE	CHOKE RELAY TO CHOKE	67
GRAY-YELLOW	ELECTRONIC CONTROL UNIT TO CANISTER PURGE SOLENOID	101
GRAY-YELLOW	HEADLAMP DIMMER SWITCH TO HEADLAMP DIMMER AMPLIFIER	505
GRAY-YELLOW	ACC FEED	687
GRAY-YELLOW	EFI MODULE TO CLUTCH SWITCH	481
GRAY-YELLOW	PRESSURE SWITCH TO INERTIA SWITCH	467
LT BLUE	REARVIEW OUTSIDE MIRROR CLOCKWISE	413
LT BLUE	ELECT. ENG. CONTL. MOD. TO ELECTRO DRIVE FAN	386
LT BLUE	VEHICLE SPEED SENSOR FEED	353
LT BLUE	ANTI-SKID MODULE TO ANTI-SKID CONTROL VALVE	677
LT BLUE	C.B. B+ DIGIT	720
LT BLUE	CAM SENDER SIGNAL RETURN	796
LT BLUE	ELECT SHIFT 4 x 4 MODULE TO SPEED SENSOR COIL	772
LT BLUE	LOW COOLANT LEVEL RELAY TO SENSOR	794
LT BLUE	HEADLAMP DIMMER RELAY TO FUSE HOLDER	503
LT BLUE	ELECTRONIC FUEL GAGE TO MESSAGE CENTER	501
LT BLUE	FUEL INJECTOR #8 CYLINDER	562
LT BLUE	LEFT FRONT SHOCK DAMPENING RELAY TO CONTROL MODULE	641
LT BLUE	RIGHT REAR AIR INPUT RETURN	855
LT BLUE	MEMORY MIRROR MODULE TO RH HORIZONTAL DRIVER	888
LT BLUE	VEHICLE MAINTENANCE MONITOR MODULE TO OIL TEMP INPUT	905
LT BLUE	LOW FUEL INDICATOR	106
LT BLUE	KEYLESS DOOR LOCK SWITCH ILLUMINATION FEED	66
LT BLUE	TURN SIGNAL FLASHER TO TURN SIGNAL SWITCH	44
LT BLUE	SEAT REG. SW. TO HORIZ. SOLENOID BATT. TERM	306
LT BLUE	INDICATOR LAMP TO SWITCH (4 x 4)	210
LT BLUE-BLACK	AMPLIFIER SPEAKER SWITCH TO LEFT REAR SPEAKER	277
LT BLUE-BLACK	BRAKE FEED	22
LT BLUE-BLACK	SPEED CONTROL ON-OFF SWITCH TO AMPLIFIER	151
LT BLUE-BLACK	MEMORY MIRROR MODULE RH VERTICAL POSITION	893
LT BLUE-BLACK	FOG LAMP SWITCH TO FOG LAMP RELAY	477
LT BLUE-BLACK	INDICATOR LAMP TO LOW RANGE SWITCH 4 x 4	784
LT BLUE-BLACK	SAFETY RELAY LOAD TERM. TO WIND. REG. SW. FEED	400
LT BLUE-BLACK	AIR SOLENOID CONTROL - REAR	416
LT BLUE-BLACK	RELAY TO DAY/NIGHT ILLUMINATION LAMPS	434
LT BLUE-ORANGE	AMBIENT SENSOR TO INST. PANEL THERMISTOR	767
LT BLUE-ORANGE	C.B. SPEAKER RELAY TO MIC	723
LT BLUE-ORANGE	DCP MODULE TO HEATED BACKLITE RELAY	624
LT BLUE-ORANGE	EEC MODULE CONTROL OF HIGH SPEED FUEL PUMP	926
LT BLUE-ORANGE	LH REAR STOP & TURN BULB OUTAGE	104
LT BLUE-ORANGE	HORN CONTROL MODULE TO OVERRIDE SWITCH	34
LT BLUE-ORANGE	HI-TENS' SWITCH TO MCU MODULE	308
LT BLUE-ORANGE	HEATER BLOWER MOTOR TO SWITCH (MEDIUM)	269
LTBLUE-PINK	EEC MODULE TO TIME METER	305
LT BLUE-PINK	ELECTRONIC CLUSTER ACCESSORY FEED	295
LT BLUE-PINK	TRANSFORMER POWER - MESSAGE CENTER TO DISPLAY	169
LT BLUE-PINK	IDLE TRACKING SWITCH FEED	189
LT BLUE-PINK	BUCKLE SW. TO CENTER OCCUPANT SEAT SENSOR	107
LT BLUE-PINK	AIR COMPRESSOR VENT SOLENOID	578
LT BLUE-PINK	BRAKE SKID CONTROL MODULE FEED	601
LT BLUE-RED	DCP MODULE CONTROL INTERFACE TO RADIO	595
LT BLUE-RED	PRESSURE SWITCH TO MODULE	535
LT BLUE-RED	C.B. SPEAKER TO TRANSCIEVER	717
LT BLUE-RED	FUEL PUMP BYPASS	433
LT BLUE-RED	FUEL LEVEL WARNING RELAY FEED	365
LT BLUE-RED	CLOCK SELECT SWITCH TO MESSAGE CENTER	142
LT BLUE-RED	INSTRUMENT PANEL LAMPS FEED	19
LT BLUE-RED	THERMACTOR DUMP VALVE FEED	255
LT BLUE-WHITE	CIGAR LIGHTER FEED	40
LT BLUE-WHITE	ARRIVAL SWITCH TO MESSAGE CENTER	152
LT BLUE-WHITE	TIMER CONTROL VALVE TO CONTROL UNIT	741
LT BLUE-WHITE	SPEAKER SWITCH GROUND TO LEFT FRONT SPEAKER	813
LT BLUE-WHITE	DCP MODULE TO PARKLAMP RELAY	625
LT BLUE-WHITE	VEHICLE MAINTENANCE MONITOR MODULE TO SPEED SENSOR	909
LT BLUE-WHITE	EEC MODULE TO TRANSMISSION	912
LT BLUE-YELLOW	HEATER & A/C CONTROL SW. (HI & LO NORM) TO BLOWER MOTOR SW. RELAY	769
LT BLUE-YELLOW	RADIATOR COOLANT TEMP SWITCH TO CONTROL UNIT	742
LT BLUE-YELLOW	CRT SCAN	730
LT BLUE-YELLOW	FUEL TANK SELECTOR SWITCH TO AFT FUEL PUMP	671
LT BLUE-YELLOW	BATTERY TO AUTOMATIC ANTENNA SWITCH	451
LT BLUE-YELLOW	CHECKOUT SWITCH TO MESSAGE CENTER	143
LT BLUE-YELLOW	KEYLESS DOOR LOCK SWITCH DATA BIT 1 TO MODULE	78
LT BLUE-YELLOW	DE-ICE SOLENOID CONTROL	241
LT BLUE-YELLOW	MODULE TO NEUTRAL SENSOR SWITCH	199
LT GREEN	SPEAKER VOICE COIL FEED FRONT (LEFT CHANNEL) AMP INPUT	280
LT GREEN	VACUUM DOOR LOCK SWITCH TO SOLENOID (LOCK)	115
LT GREEN	KEYLESS DOOR LOCK OUTPUT FROM MODULE	129
LT GREEN	READING LAMP SWITCH TO READING LAMP (LH)	387
LT GREEN	C.B. A-DIGIT	715
LT GREEN	WINDSHIELD WASHER	726
LT GREEN	ELECT SHIFT 4 x 4 MODULE TO SPEED SENSOR RETURN	774
LT GREEN	AIR SUSPENSION CONTROL SIGNAL	637
LT GREEN	ALTERNATOR RELAY TO ALTERNATOR REGULATOR	568
LT GREEN	FUEL INJECTOR #6 CYLINDER	560
LT GREEN	STOPLAMP SWITCH TO TURN SIGNAL SWITCH	511
LT GREEN	RADIO TO FADER CONTROL	823
LT GREEN	SPEED CONTROL VACUUM TO EEC MODULE	916
LT GREEN	SEAT BELT WARNING SWITCH FEED	469
LT GREEN	LEFT LIMIT-B-DRIVER	872
LT GREEN-BLACK	ESC SWITCH TO ESC VALVE CONTROL	933
LT GREEN-BLACK	LH REAR SENSOR (LOW) TO MODULE	519
LT GREEN-BLACK	DCP MODULE TRIP SCAN HIGH TO TRIPMINDER	597
LT GREEN-BLACK	C.B. REGULATED 5V	711
LT GREEN-BLACK	MANIFOLD ABSOLUTE PRESSURE SENSOR FEED	358
LT GREEN-BLACK	CONTROL MODULE TO OIL PRESSURE SWITCH	473
LT GREEN-BLACK	SEQUENTIAL LH REAR OUTBOARD TURN SIGNAL LAMP	444
LT GREEN-BLACK	AIR PORT SOLENOID SIGNAL	99
LT GREEN-BLACK	HEADLAMP DIMMER SWITCH TO HIGH BEAMS	12
LT GREEN-ORANGE	LH REAR TURN SIGNAL LAMP	9
LT GREEN-ORANGE	POWER SERVO TO CLIMATE CONTROL UNIT (MODE)	243
LT GREEN-ORANGE	AIR SOLENOID CONTROL L.F.	415
LT GREEN-ORANGE	SEQUENTIAL LH REAR INBOARD TURN SIGNAL LAMP	442
LT GREEN-ORANGE	C.B. NOISE BLANKER	705
LT GREEN-ORANGE	AMPLIFIER SWITCH GROUND TO RIGHT FRONT SPEAKER	815
LT GREEN-ORANGE	W/W WIPER SWITCH TO W/S WIPER MOTOR FIELD RH	956
LT GREEN-PURPLE	SUPERCHARGER SOLENOID #1	965
LT GREEN-PURPLE	AMPLIFIER SWITCH FEED TO RIGHT FRONT SPEAKER	816
LT GREEN-PURPLE	BATTERY FEED TO STEREO	797
LT GREEN-PURPLE	DCP MODULE TRIP SCAN LOW TO TRIPMINDER	598
LT GREEN-PURPLE	ELECTRONIC SHOCK HARD CONTROL	838
LT GREEN-PURPLE	THERMOSTATIC SW. TO AIR COND. SW. SELECTOR TERM.	348
LT GREEN-PURPLE	START INTERRUPT RELAY TO ANTI-THEFT MODULE	342
LT GREEN-PURPLE	CARBURETOR AIR TEMPERATURE SENSOR FEED	357
LT GREEN-PURPLE	FUEL PULSE TO MESSAGE CENTER	139
LT GREEN-RED	KEYLESS DOOR LOCK SWITCH DATA BIT 2 TO MODULE	79
LT GREEN-RED	STOPLAMP SWITCH FEED	10
LT GREEN-RED	EMERG. BRAKE WARNING LAMP TO EMERG. BRAKE SWITCH	162
LT GREEN-RED	SEQUENTIAL LH REAR CENTER TURN SIGNAL LAMP	443
LT GREEN-RED	(COIL) OR (ACCY) TERM OF IGNITION SWITCH TO ALTERNATOR REGULATOR (IGN. TERM)	904
LT GREEN-RED	REAR SENSOR (HIGH) TO MODULE	518
LT GREEN-RED	AIR SUSPENSION SYSTEM GROUND	577
LT GREEN-RED	LEFT CHANNEL SIGNAL OUT	798
LT GREEN-RED	C.B. RELAY DRIVE	722
LT GREEN-WHITE	BLOWER MOTOR SPEED CONTROLLER TO RESISTOR #1 (MED.)	754
LT GREEN-WHITE	AMPLIFIER SWITCH GROUND TO LEFT FRONT SPEAKER	819
LT GREEN-WHITE	C.B. C+ DIGIT	724
LT GREEN-WHITE	MODULE TO OVERRIDE SWITCH	661
LT GREEN-WHITE	OVERDRIVE CANCEL INDICATOR LAMP	911
LT GREEN-WHITE	ELECTRONIC SHOCK SOFT CONTROL	839
LT GREEN-WHITE	ELECT. ENG. CONTL. MOD. TO IDLE SPD. CONTL. MOTOR #2	265
LT GREEN-WHITE	MEMORY SEAT SWITCH LAMP ENABLE	271
LT GREEN-WHITE	LH FRONT TURN SIGNAL LAMP	3
LT GREEN-YELLOW	SEAT SWITCH ARM TERM. TO RELAY FIELD TERM	7
LT GREEN-YELLOW	INTERIOR LAMP SWITCH FEED	54
LT GREEN-YELLOW	RETARD VALVE TO CONTROL RELAY TERM. #1	869
LT GREEN-YELLOW	FUEL TANK SELECTOR SWITCH TO MIDSHIP FUEL PUMP	672
LT GREEN-YELLOW	MODULE TO MOTOR FEED	663
LT GREEN-YELLOW	HEATER & NC CONTROL SW. TO REHEAT & A/C FEED	765
LT GREEN-YELLOW	REFERENCE SENSOR TO HEAT DUCT THERMISTOR	768
LT GREEN-YELLOW	PRESSURE SWITCH TO FLUID RES. SWITCH	547
LT GREEN-YELLOW	SPICE #3 TO POWER RELAY	530
LT GREEN-YELLOW	ENGINE COOLANT TEMPERATURE SENSOR FEED	354
ORANGE	MODULE TO RELAY	461

COLOR	DESCRIPTION *	CIRCUIT
ORANGE	WINDSHIELD WIPER SWITCH TO INTERMITTENT GOVERNOR GROUND	589
ORANGE	HEATED WINDSHIELD SWITCH TO HEATED WINDSHIELD CONTROL	582
ORANGE	BRAKE PRESSURE SWITCH TO CONTROL MODULE	636
ORANGE	ELECT SHIFT 4 x 4 MODULE TO MOTOR CONTROL	778
ORANGE	BRAKE PRESSURE SWITCH TO CONTROL MODULE	636
ORANGE	SPEAKER VOICE COIL FEED LEFT FRONT CHANNEL AMP INPUT	649
ORANGE	MODULE DIAGNOSTIC	693
ORANGE	C.B. C-DIGIT	704
ORANGE	MULTIPLEX RELAY COIL FEED	699
ORANGE	FUEL CONTROL SWITCH TO FUEL CONTROL VALVE	974
ORANGE	BATTERY FEED TO RELAY CONTROLLER	931
ORANGE	RIGHT MOTOR-PASSENGER - F	864
ORANGE	VALVE #2 TO MODULE	496
ORANGE	MEMORY MIRROR MODULE RH HORIZONTAL POSITION	892
ORANGE	FUEL SENSOR GROUND TO E.C.U.	89
ORANGE	SWITCH OFF TO RELAY	274
ORANGE	HEATER & A/C CONTROL SW. (LO-NORM) TO POWER SERVO	250
ORANGE	ELECTRONIC CLUSTER FROM EXPANDED FUEL IN KEYBOARD	285
ORANGE	16 GA FUSE LINK	300
ORANGE	RELAY TO SEAT LATCH SOLENOID	172
ORANGE-BLACK	BLOWER MOTOR TO SWITCH - HI	261
ORANGE-BLACK	TAIL LAMP BULB OUTAGE TO MESSAGE CENTER	132
ORANGE-BLACK	ELECTRIC CHOKE FEED	68
ORANGE-BLACK	EVO MODULE TO TEST CONNECTOR	927
ORANGE-BLACK	TRANSMISSION OIL TEMP	923
ORANGE-BLACK	MULTIPLEX FARRING LAMPS	696
ORANGE-BLACK	CLIMATE CONTROL BOX TO HIGH BLOWER RELAY	776
ORANGE-BLACK	RIGHT CHANNEL SIGNAL OUT	799
ORANGE-BLACK	ENGLISH METRIC SIGNAL TO MULTIGAGE	572
ORANGE-BLACK	LIQUID CRYSTAL DISPLAY	484
ORANGE-BLACK	TURN SIGNAL SWITCH TO INDICATOR RELAY	458
ORANGE-BLACK	AIR SUSPENSION HEIGHT SENSOR LO-REAR	428
ORANGE-BLACK	IDLE SPEED CONTROL TO EGR VACUUM SOLENOID	323
ORANGE-BLACK	RADIO SEEK "DOWN"	370
ORANGE-LT BLUE	AFTER GLOW RELAY TO DIESEL CONTROL SWITCH	335
ORANGE-LT BLUE	SEQUENTIAL RH REAR INBOARD TURN SIGNAL LAMP	445
ORANGE-LT BLUE	1 TERMINAL STARTER MOTOR RELAY TO INERTIA SWITCH	668
ORANGE-LT BLUE	ELECT SHIFT TO 4L SWITCH	781
ORANGE-LT BLUE	RADIO RECEIVER ASSY. TO FOOT CONTROL SWITCH	747
ORANGE-LT BLUE	VAC SWITCH TO VAC PUMP	740
ORANGE-LT BLUE	RH REAR TURN SIGNAL LAMP	5
ORANGE-LT BLUE	ALTERNATOR REGULATOR "F" TERMINAL TO ALTERNATOR	35
ORANGE-LT BLUE	ELECTRONIC CONTROL UNIT TO WIDE OPEN THROTTLE ACTUATOR	73
ORANGE-LT BLUE	FUEL SUPPLY PUMP RELAY	238
ORANGE-LT BLUE	CRUISE INDICATING LAMP TO CRUISE LAMP INTERFACE MODULE	203
ORANGE-LT GREEN	TANK SELECT CIRCUIT ELECTRONIC FUEL GAUGE	204
ORANGE-LT GREEN	EMA CONTROL TO EGR SWITCH	27
ORANGE-LT GREEN	AIR BAG DIAGNOSTIC MODULE TO AIR BAG FLASHER	610
ORANGE-LT GREEN	DCP MODULE TO WIPER HI-LO RELAY	594
ORANGE-LT GREEN	SPEAKER VOICE COIL FEED - FRONT (LEFT CHANNEL)	804
ORANGE-LT GREEN	DECELERATION SENSOR	847
ORANGE-LT GREEN	INDICATOR RELAY TO FLASHER	459
ORANGE-LT GREEN	DROPPING RESISTOR TO RELAY #2	471
ORANGE-RED	SEQUENTIAL RH REAR OUTBOARD TURN SIGNAL LAMP	447
ORANGE-RED	AIR SOLENOID CONTROL R.F.	414
ORANGE-RED	RESISTOR TO BLOWER MOTOR (HI)	515
ORANGE-RED	SKID CONTROL MODULE RH WHEEL SENSOR (HI)	604
ORANGE-RED	AMPLIFIER/SPEAKER SWITCH FEED TO RIGHT REAR SPEAKER	802
ORANGE-RED	LO-TEMP SWITCH TO MCU MODULE	309
ORANGE-RED	INSTRUMENT PANEL ILLUMINATION CONTROL MODULE FEED	293
ORANGE-WHITE	TEMPERATURE COMPENSATED PUMP TO PROCESSOR	256
ORANGE-WHITE	HEADLAMP SWITCH TO SENSOR AND AUTOLAMP AMPLIFIER	221
ORANGE-WHITE	AIR DUMP VALVE NEG. TO EXHAUST SYS. OVERTEMP MODULE	93
ORANGE-WHITE	ELECT SHIFT 4 x 4 MODULE TO MOTOR POSITION #2	763
ORANGE-WHITE	ACCELERATE DECELERATE SENSOR	836
ORANGE-WHITE	VENT SWITCH TO LEFT FRONT VENT MOTOR	886
ORANGE-WHITE	SEQUENTIAL RH REAR CENTER TURN SIGNAL LAMP	446
ORANGE-WHITE	POWER RELAY TO GLOW PLUGS (LEFT BANK)	337
ORANGE-WHITE	SENSOR SIGNAL FEED	351
ORANGE-WHITE	DOOR OPENING WARNING TO ANTI-THEFT MODULE	341
ORANGE-WHITE	MOVABLE STEERING COLUMN SOLENOID TO COURTESY LAMP SWITCH	381
ORANGE-YELLOW	ANTENNA SWITCH TO ANTENNA RELAY	448
ORANGE-YELLOW	OVERRIDE SWITCH 10 LATCH	665
ORANGE-YELLOW	AIR BAG READY INDICATOR LAMP TO AIR BAG FLASHER	609
ORANGE-YELLOW	SPlice TO DIODE	531
ORANGE-YELLOW	SPlice TO POWER RELAY	532
ORANGE-YELLOW	SPlice TO MODULE	525
ORANGE-YELLOW	POWER RELAY TO MODULE GROUND	528
ORANGE-YELLOW	SPEED SENSOR LO V REF TO SPEEDO TACH MODULE	563
ORANGE-YELLOW	AMPLIFIER TO SERVO TRANSDUCER FEED	144
ORANGE-YELLOW	TURN SIGNAL FLASHER FEED	8
ORANGE-YELLOW	SEAT SWITCH TO RELAY FIELD TERMINAL	18
ORANGE-YELLOW	TRANSMISSION THROTTLE VALVE SOLENOID 1	237
ORANGE-YELLOW	START CIRCUIT TO THERMACTOR RELAY	253
PINK	WINDOW REGULATOR RELAY ACCY FEED	194
PINK	HIGH ELECTRO DRIVE FAN	639
PINK	MULTIPLEX MESSAGE I	736
PINK	EEC MODULE TO SPARK ADVANCE	929
PINK	AIR COMPRESSOR VENT SOLENOID	421
PINK	VALVE #4 TO MODULE	498
PINK	CRANK ENABLE RELAY	329
PINK-BLACK	ELECTRONIC CLUSTER IGNITION RUN FEED	489
PINK-BLACK	STOPLAMP RELAY FEED	474
PINK-BLACK	AIR SUSPENSION HEIGHT SENSOR HI - L.F.	422
PINK-BLACK	AIR SUSPENSION HEIGHT SENSOR HI-REAR	427
PINK-BLACK	COMPASS SENSOR FEED	684
PINK-BLACK	FUEL PUMP SAFETY SWITCH TO FUEL PUMP MOTOR	787
PINK-BLACK	SENSOR AMPLIFY UNIT TO CONTROL UNIT #1	749
PINK-BLACK	RH REAR SENSOR (LOW) TO MODULE	524
PINK-BLACK	AIR BAG DIAGNOSTIC MODULE TO PASSENGER INFLATOR	616
PINK-BLACK	SHOCK DAMPENING RELAY HARD TO SHOCK DAMPENING CONTROL	652
PINK-BLACK	SPEAKER VOICE COIL FEED RIGHT REAR CHANNEL AMP INPUT	645
PINK-BLACK	THERMO SWITCH TO CONTROL MODULE	470
PINK-BLACK	DOOR LOCK MOTOR (LOCK)	117
PINK-LT BLUE	RH HEADLAMP BULB OUTAGE	109
PINK-LT BLUE	AIR COND. CONTROL RELAY FEED	883
PINK-LT BLUE	PRESSURE SWITCH TO MOTOR RELAY	539
PINK-LT BLUE	SPEAKER VOICE COIL FEED-REAR (RIGHT CHANNEL)	806
PINK-LT BLUE	AMPLIFIER/SPEAKER SWITCH GROUND TO LEFT REAR SPEAKER	801
PINK-LT BLUE	EEC MODULE-DATA MINUS	915
PINK-LT GREEN	VENT SWITCH TO BLOWER MOTOR-LO	917
PINK-LT GREEN	SPEAKER VOICE COIL FEED-REAR (LEFT CHANNEL)	807
PINK-LT GREEN	EEC MODULE TO CHECK ENGINE INDICATOR LAMP	658
PINK-LT GREEN	MODULE TO SOLENOID	599
PINK-LT GREEN	DOOR LOCK SWITCH (UNLOCK)	120
PINK-ORANGE	DOOR LOCK MOTOR (UNLOCK)	118
PINK-ORANGE	AIR BAG DIAGNOSTIC MODULE (DEPLOY) TO RH SENSOR	617
PINK-ORANGE	SPEAKER SWITCH FEED TO RIGHT FRONT SPEAKER	812
PINK-ORANGE	READING LAMP SWITCH TO READING LAMP	487
PINK-ORANGE	MEMORY MIRROR MODULE LH HORIZONTAL POSITION	896
PINK-ORANGE	DIESEL CONTROL MODULE FEED	466
PINK-ORANGE	ELECT. ENG. CONTL. MOD. TO IDLE SPD CONTL. MOTOR #3	384
PINK-WHITE	BLOWER MOTOR RELAY TO MOTOR	371
PINK-WHITE	AIR SUSP. MOD. TO L.F. HEIGHT SENSOR	431
PINK-WHITE	AIR BAG DIAGNOSTIC MODULE (DEPLOY) TO CENTER SENSOR	619
PINK-WHITE	SPEAKER SWITCH FEED TO LEFT FRONT SPEAKER	814
PINK-WHITE	DOOR SWITCH TO SEAT LATCH RELAY (COIL TERM.)	173
PINK-YELLOW	DOOR LOCK SWITCH (LOCK)	119
PINK-YELLOW	WASHER FLUID LEVEL INDICATOR	82
PINK-YELLOW	DPC MODULE TO HEADLAMP RELAY	632
PINK-YELLOW	SPEAKER VOICE COIL FEED LEFT REAR CHANNEL AMP INPUT	646
PINK-YELLOW	OPEN DOOR WARNING LAMP FEED	626
PINK-YELLOW	SWITCH TO FADER RIGHT CHANNEL FEED	830
PURPLE	RIGHT FRONT SHOCK DAMPENING RELAY TO CONTROL MODULE	638
PURPLE	HEATED WINDSHIELD CONTROL TO EEC AIR COND TERM	585
PURPLE	CONVERTIBLE TOP RELAY TO SWITCH	588
PURPLE	R.H. REMOTE MIRROR MOTOR FEED-C.C.W.	544
PURPLE	HEADLAMP DIMMER SWITCH TO HEADLAMP DIMMER RELAY	500
PURPLE	C.B. A+ DIGIT	712
PURPLE	RELAY COIL FEED #2	714
PURPLE	REDUNDANT MODULE TO ENGINE WARNING LAMP	656
PURPLE	POWER FEED FROM AMPLIFIER	928

* IN SOME CASES, THERE MAY BE ADDITIONAL CIRCUIT FUNCTIONS INCLUDED IN THE CIRCUIT DESCRIPTION LISTED.

STANDARD CIRCUIT CHART (BY COLOR)

COLOR	DESCRIPTION *	CIRCUIT	COLOR	DESCRIPTION *	CIRCUIT
PURPLE	LEFT CHANNEL SIGNAL	856	TAN	VALVE #1 TO MODULE	495
PURPLE	MODULE TO RELAY	462	TAN	RIGHT LIMIT-B-PASSENGER	873
PURPLE	TRANSMISSION DIAGNOSTIC	453	TAN	WINDOW REG. SW. TO BACK WINDOW AUX. SW.	406
PURPLE	POWER SERVO TO CLIMATE CONTROL UNIT (AMP)	246	TAN	AIR SUSPENSION HEIGHT SENSOR HI- R.F.	424
PURPLE	ELECTRONIC CLUSTER FROM TRIP RECALL SWITCH IN KEYBOARD	288	TAN-BLACK	PRESSURE SWITCH TO KEY SWITCH	409
PURPLE BASE	EATC RH SUNLOAD SENSOR POSITIVE	479	TAN-BLACK	BRAKE WEAR SENSOR	457
PURPLE-LT BLUE	WINDOW REG. SW. TO BACK WINDOW SW.	405	TAN-BLACK	WINDOW REG. SW. REAR TO LIMIT SW.	407
PURPLE-LT BLUE	SPEED CONTROL SENSE EEC MODULE TO CLUSTER	683	TAN-BLACK	ELECTRONIC SHOCK FEEDBACK ACTUATOR TO RELAY	845
PURPLE-LT BLUE	AIR BAG DIAGNOSTIC MODULE (MONITOR) TO CENTER SENSOR	620	TAN-BLACK	DIGITAL AUDIO DISC LOGIC SENSOR	849
PURPLE-LT BLUE	POWER FEED-SWITCH 10 REAR AMPLIFIER	828	TAN-BLACK	MEMORY MIRROR MODULE TO LH VERTICAL DRIVE	897
PURPLE-LT BLUE	CLICKER RELAY TERM. NO.41D AIR VALVE ASSY.	263	TAN-BLACK	LH FRONT SENSOR (LOW) TO MODULE	522
PURPLE-LT BLUE	AMPLIFIER FEEDBACK POTENTIOMETER FEED	147	TAN-BLACK	AIR BAG DIAGNOSTIC MODULE (MONITOR) TO LH SENSOR	622
PURPLE-LT GREEN	DESTINATION SWITCH 70 MESSAGE CENTER	154	TAN-BLACK	VEHICLE MAINTENANCE MONITOR MODULE TO ENGINE STRAP	908
PURPLE-LT GREEN	AIR BAG DIAGNOSTIC MODULE (MONITOR) TO RH SENSOR	618	TAN-LT BLUE	MODULATOR TO THERMO. SWITCH	939
PURPLE-LT GREEN	REAR WASHER PUMP FEED	946	TAN-LT BLUE	MASS AIR FLOW RETURN	968
PURPLE-LT GREEN	VEHICLE MAINTENANCE MONITOR MODULE TO ELEC. INSTR CLUST. SENSE	907	TAN-LT BLUE	FUEL INJECTOR #5 CYLINDER	559
PURPLE-LT GREEN	WINDOW REG. SW. TO BACK WINDOW SW.	404	TAN-LT BLUE	INDICATOR RELAY TO RH TURN LAMP	817
PURPLE-LT GREEN	AIR SUSPENSION HEIGHT SENSOR LO- L.F.	423	TAN-LT BLUE	TRANSMISSION OVERDRIVE SWITCH TO EEC MODULE	224
PURPLE-LT GREEN	REAR AIR SUSPENSION HEIGHT SENSOR FEED	429	TAN-LT BLUE	AUTOLAMP AMPLIFIER TO RHEOSTAT	216
PURPLE-ORANGE	AIR SUSPENSION SWITCH FEED	417	TAN-LT BLUE	FEEDBACK CARET. COIL 4	98
PURPLE-ORANGE	AIR BAG READY INDICATOR L (MONITOR) TO SAFING SENSOR	612	TAN-LT GREEN	FEEDBACK CARE. COIL 3	97
PURPLE-ORANGE	CIGAR LIGHTER LAMP FEED	131	TAN-LT GREEN	ANTI-THEFT SYSTEM SWITCH FEED	23
PURPLE-ORANGE	FUSED ACCY FEED #2	298	TAN-LT GREEN	ODOMETER SENSOR TO EEC MODULE	223
PURPLE-ORANGE	AUTOLAMP AMPLIFIER TO CONTROL SWITCH	220	TAN-LT GREEN	AMPLIFIER SWITCH FEED TO RIGHT REAR SPEAKER	825
PURPLE-WHITE	AMPLIFIER SPEAKER SWITCH FEED TO RIGHT REAR SPEAKER	278	TAN-LT GREEN	BRAKE FLUID RES. SWITCH TO MODULE	512
PURPLE-WHITE	MEMORY SEAT SWITCH ENABLE	266	TAN-ORANGE	TURN SIGNAL RELAY TO TURN SIGNAL FLASHER	494
PURPLE-WHITE	AIR BAG DIAGNOSTIC MODULE (MONITOR) TO SAFING SENSOR	623	TAN-ORANGE	LH FRONT SENSOR (HIGH) TO MODULE	521
PURPLE-WHITE	SEAT BELT WARNING LAMP TO WARNING LAMP SWITCH	520	TAN-ORANGE	FUEL INJECTOR #7 CYLINDER	561
PURPLE-WHITE	HEATER & A/C CONTROL SW (LO-HI-NORM) TO RESISTOR (LOW RANGE)	758	TAN-ORANGE	EEC MODULE-DATA PLUS	914
PURPLE-WHITE	MULTIPLEX SERVICE REMINDER RESET	733	TAN-ORANGE	FOG LAMP SW. TO FOG LAMP	478
PURPLE-WHITE	BRAKE WARNING SWITCH TO INDICATOR LAMP	977	TAN-ORANGE	COOLANT TEMPERATURE SWITCH TO CONTROL RELAY	197
PURPLE-WHITE	RIGHT MOTOR - PASSENGER - R	865	TAN-ORANGE	AIR COND. SW. (LO) TO AIR COND. BLOWER MOTOR	184
PURPLE-YELLOW	LEFT MOTOR - DRIVER-F	860	TAN-ORANGE	FEEDBACK CARE. COIL 2	96
PURPLE-YELLOW	ELECT SHIFT 4 x 4 MODULE TO MOTOR POSITION #5	771	TAN-RED	FEEDBACK GARB. COIL 1	95
PURPLE-YELLOW	CLUTCH SWITCH TO EFI MODULE	480	TAN-RED	RELAY TO MAP LAMP SWITCH	133
PURPLE-YELLOW	TURN SIGNAL SWITCH TO LH CORNERING LAMP	380	TAN-RED	MCV MODULE TO VIP FUNCTION TESTER	201
PURPLE-YELLOW	FUEL INJECTION PUMP POSITION SENSOR	239	TAN-RED	THERMACTOR TIMER TO RELAY	252
PURPLE-YELLOW	BRAKE FLUID LEVEL UNIT TO MESSAGE CENTER	128	TAN-RED	ELECTRONIC SHOCK METAL OXIDE VERISTOR	846
PURPLE-YELLOW	ECONOMY SWITCH TD MESSAGE CENTER	153	TAN-RED	MEMORY MIRROR MODULE TO LH HORIZONTAL DRIVE	898
PURPLE-YELLOW	DECK LID SOLENOID FEED	84	TAN-RED	POWER RELAY TO FUSE LINK	533
RED	KEYLESS DOOR LOCK SWITCH DATA BIT 5 TO MODULE	123	TAN-RED	VALVE #6 TO MODULE	510
RED	TRAILER BRAKES	50	TAN-RED	MULTIPLEX COMPUTER FEED	792
RED	SUPPLEMENTAL ALTERNATOR STATOR A TERM. TO WINDSHIELD	70	TAN-RED	HEATED WINDSHIELD TRIGGER CIRCUIT SW. TO MODULE	681
RED	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	63	TAN-RED	WINDOW REG. SW. FRONT TO LIMIT SW.	408
RED	18 GA FUSE LINK	301	TAN-WHITE	AMPLIFIER SWITCH FEED TO LEFT REAR SPEAKER	827
RED	HORIZONTAL SEAT REG. MOTOR TO RELAY	180	TAN-WHITE	IDLE RPM SOLENOID TO CONTROL UNIT	744
RED	POWER RELAY TO EEC MODULE	361	TAN-WHITE	INDICATOR RELAY TO LH TURN LAMP	818
RED	REAR VIEW OUTSIDE MIRROR FEED	388	TAN-WHITE	EMISSION SPEED SENSOR TO MODULATOR CONTROL	934
RED	WIDE OPEN THROTTLE NC CUTOUT SWITCH	331	TAN-WHITE	TAILLAMP SWITCH FEED	195
RED	POWER LUMBAR FEED	490	TAN-WHITE	INTERLOCK MODULE TO CENTER SEAT SENSOR SWITCH	87
RED	FUEL TANK SELECTOR TO FUEL PUMP FRONT	786	TAN-YELLOW	NC PRESSURE SWITCH TO CONTROL RELAY	198
RED	DIESEL WATER IN FUEL SENDER TO WARNING LAMP	643	TAN-YELLOW	tone GENERATOR	183
RED	BATTERY FEED CAMPER	666	TAN-YELLOW	AIR COND. CONDENSOR THERMAL SWITCH FEED	509
RED	AMPLIFIER POWER RETURN	694	TAN-YELLOW	FUSE LINK TO MOTOR RELAY	537
RED	INERTIA SWITCH TO FUEL TANK SELECTOR SWITCH	670	TAN-YELLOW HASH	FEED TO VACUUM DOOR LOCK SWITCH	114
RED	EED MODULE TO SPEED CONTROL GROUND	676	WHITE	KEYLESS DOOR LOCK OUTPUT (ALL) FROM MODULE	134
RED	MOONROOF RELAY TO MICRO SWITCH CLOSED	692	WHITE	ASH RECEPTACLE LAMP FEED	17
RED	HEADLAMP DIMMER SWITCH OVERRIDE TO RHEOSTAT	527	WHITE	TRAILER GROUND	49
RED	MPH/KPH SWITCH TO MESSAGE CENTER	506	WHITE	WINDSHIELD WIPER SW. TO WINDSHIELD WIPER MOTOR	58
RED	L.H. REMOTE MIRROR MOTOR FEED-C.W.	540	WHITE	SUPPLEMENTAL ALTERNATOR STATOR B TERM. TO WINDSHIELD	71
RED	HEATED WINDSHIELD CONTROL TO ALT STATOR TERM	581	WHITE	REAR WINDOW REGULATOR SWITCH FEED	176
RED	SOLENOID	605	WHITE	KEYLESS DOOR LOCK SEAT SWITCH SENSOR TO MODULE	177
RED	STEERING RATE SENSOR TERMINAL A CONTROL MODULE	633	WHITE	GROUND RETURN TO TOWING VEHICLE	206
RED	DOOR WIRE	630	WHITE	ELECTRONIC CLUSTER FROM GAUGE SELECT SWITCH IN KEYBOARD	289
RED	STEERING RATE SENSOR TERMINAL A CONTROL MODULE	633	WHITE	SPEAKER VOICE COIL RETURN AMP INPUT	281
RED	BATTERY FEED TO AUX. FUEL SELECTOR SWITCH	973	WHITE	SEAT REG. SW. TO VERT. SOLENOID BATT. TERM.	307
RED	TOP CONTROL RELAY TO MOTOR-DOWN	903	WHITE	R.H. REMOTE MIRROR SOLENOID CONTROL	545
RED	RIGHT DOOR OPEN - PASSENGER	863	WHITE	FUEL INJECTOR #2 CYLINDER	556
RED-BLACK	MEMORY MIRROR MODULE POSITION +	891	WHITE	RHEOSTAT TO SENSOR	508
RED-BLACK	VENT CROSSOVER FEED	879	WHITE	DOOR WIRE	628
RED-BLACK	MODE SELECT SWITCH LAMP	833	WHITE	ELECT SHIFT 4 X 4 MODULE TO MOTOR POSITION #4	770
RED-BLACK	WATER TEMP. WARNING LAMP TO WATER TEMP. SW. (HOT)	647	WHITE	C.B. MIC-AUDIO	713
RED-BLACK	FRONT AIR SUSPENSION HEIGHT SENSOR FEED	426	WHITE	RELAY COIL FEED #3	725
RED-BLACK	ELECT. ENG. CONTRL. MOD. TO WIDE OPEN THROTTLE KICKER SOC.	378	WHITE	RIGHT REAR SHOCK DAMPENING RELAY TO CONTROL MODULE	650
RED-BLACK	FUEL WARNING RELAY CONTROL	366	WHITE	ACTUATOR POSITION SENSOR RIGHT REAR	843
RED-BLACK	RADIO "SEEK UP"	368	WHITE	VALVE #3 TO MODULE	497
RED-BLACK	ECU TO VACUUM SWITCH 3	214	WHITE	INERTIA SWITCH TO MODULE	866
RED-BLACK	LAMP RETURN TO PULSE WITH DIMMER	235	WHITE	ELECT. ENG. CONTRL. MOD. 70 EXHAUST HEAT CONTRL SOC.	377
RED-BLACK	LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT FRONT WINDOW REGULATOR MOTOR	314	WHITE	TIME DELAY RELAY	332
RED-BLACK	LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT REAR WINDOW REGULATOR MOTOR	320	WHITE	REARVIEW OUTSIDE MIRROR COUNTERCLOCKWISE	412
RED-BLACK	HEADLAMP DIMMER SWITCH TO LOW BEAMS	13	WHITE BASE	LH REAR TAIL LAMP BULB OUTAGE	102
RED-LT BLUE	STARTER CONTROL	32	WHITE-BLACK	THERMOCOUPLE 2 NEG. TO EXHAUST SYST. OVERTEMP PROTECT MODULE	92
RED-LT BLUE	WINDOW REGULATOR SWITCH FEED	170	WHITE-BLACK	ELAPSED TIME SWITCH TO MESSAGE CENTER	165
RED-LT BLUE	ANTI-THEFT MODULE TO ALARM RELAY	340	WHITE-BLACK	ALTERNATOR REG. "S" TERM. TO ALTERNATOR "S" TERM.	4
RED-LT BLUE	LEFT FRONT WINDOW REGULATOR SWITCH TO LEFT REAR WINDOW REGULATOR MOTOR	317	WHITE-BLACK	LF WINDOW REG. SW. TO LF WINDOW REG. MOTOR	226
RED-LT BLUE	SEAT PROCESSOR TO RECLINER MOTOR "DOWN"	440	WHITE-BLACK	5V TO-MESSAGE CENTER TO DISPLAY	168
RED-LT BLUE	TACHOMETER FEED	648	WHITE-BLACK	HEADLAMP SWITCH TO AUXILIARY LAMPS	188
RED-LT BLUE	SEAT REGULATOR SWITCH TO FRONT MOTOR (LH)	979	WHITE-BLACK	THERMACTOR DIVERTER VALVE FEED	200
RED-LT BLUE	SEAT REGULATOR SWITCH TO FRONT MOTOR (RH)	985	WHITE-BLACK	THROTTLE KICKER RELAY TO MCU MODULE	393
RED-LT BLUE	VENT CROSSOVER FEED	880	WHITE-BLACK	ACTUATOR POSITION SENSOR LEFT FRONT	840
RED-LT BLUE	AMPLIFIER TO SPEED SENSOR RETURN	901	WHITE-BLACK	MODULE TO MOTOR FEED	662
RED-LT GREEN	COIL TERM. OF IGN. SW. TO BRAKE SKID CONTROL MODULE	602	WHITE-BLACK	C.B. PUSH TO TALK	702
RED-LT GREEN	STOPLAMP SW. TO STOPLAMPS	810	WHITE-BLACK	MULTIPLEX REVERSE DIMMING	731
RED-LT GREEN	HEATER & NC CONTROL SW. (DE-FOG) TO INLET AIR CONTROL SOLENOID	766	WHITE-BLACK	THERMACTOR CLUTCH RELAY TO CLUTCH	567
RED-LT GREEN	SEAT REGULATOR SWITCH TO REAR MOTOR (LH)	983	WHITE-BLACK	WASHER CONTROL SWITCH FEED	950
RED-LT GREEN	SEAT REGULATOR SWITCH TO REAR MOTOR (RH)	989	WHITE-LT BLUE	MODULE TO DOWN SWITCH	659
RED-LT GREEN	REAR TILT POSITION SENSE	436	WHITE-LT BLUE	SURE TRACK DIAGNOSTIC	606
RED-LT GREEN	IGN. SW. COIL TERM. TO CIRCUIT BREAKER	454	WHITE-LT BLUE	C.B. VOLUME CONTROL	709
RED-LT GREEN	IGNITION SWITCH TO IGNITION COIL "BATT" TERMINAL	16	WHITE-LT BLUE	TEMP SWITCH TO WARNING DEVICE	737
RED-LT GREEN	MODULE TO THROTTLE ACTUATOR	69	WHITE-LT BLUE	STARTER INTERRUPT RELAY TO NEUTRAL START SWITCH	900
RED-LT GREEN	HEADLAMP BULB OUTAGE TO MESSAGE CENTER	130	WHITE-LT BLUE	VEHICLE MAINTENANCE MONITOR MODULE TO OIL TEMP OUTPUT	906
RED-ORANGE	KEYLESS DOOR LOCK OUTPUT (DRIVER) FROM MODULE	163	WHITE-LT BLUE	MODULE TO SWITCH	465
RED-ORANGE	IDLE SPEED CONTROL TO EGR VENT SOLENOID	322	WHITE-LT BLUE	FUSED ACCY FEED #3	294
RED-ORANGE	BLOWER MOTOR TO SWITCH - LO	260	WHITE-LT BLUE	ELECT. ENG. CONTRL. MOD. TO IDLE SPD. CONTRL. MOTOR #1	264
RED-ORANGE	W/S WIPER MOTOR ARM RH TO W/S WIPER SWITCH	955	WHITE-LT BLUE	RH FRONT TURN SIGNAL LAMP	2
RED-ORANGE	DCP MODULE TO WIPER GOVERNOR RELAY	593	WHITE-LT BLUE	DISTRIBUTOR ELECTRONIC CONTROL FEED	20
RED-ORANGE	STARTING MOTOR RELAY SHUNT TO AMMETER	655	WHITE-LT GREEN	RH AND LH REAR RUNNING LAMP BULB OUTAGE	110
RED-PINK	RH REAR SENSOR (HIGH) TO MODULE	523	WHITE-LT GREEN	AUX WATER VALVE FEED	456
RED-PINK	HEATER & A/C CONTROL SW. (HI-NORM) TO RESISTOR (LOW RANGE)	756	WHITE-LT GREEN	C.B. SCAN SWITCH	710
RED-PINK	ANTENNA SWITCH 70 POWER ANTENNA (UP)	745	WHITE-LT GREEN	BLOWER MOTOR RELAY TO ENG. WATER TEMP. SWITCH (COLD)	761
RED-PINK	SPEED CONTROL AMPLIFIER 10 CRUISE LAMP INTERFACE MODULE	202	WHITE-LT GREEN	WATER TEMP. WARNING LAMP TO WATER TEMP. SW. (COLD)	642
RED-PINK	DOOR JAMB SWITCH TO BUZZER	159	WHITE-LT GREEN	SPEAKER VOICE COIL FEED - FRONT (RIGHT CHANNEL)	805
RED-WHITE	RH REAR STOP & TURN BULB OUTAGE	105	WHITE-ORANGE	HEATER & NC CONTROL SW. TO INST. PANEL THERMISTOR	790
RED-WHITE	TEMP. GAUGE TO TEMP. SENDING UNIT	39	WHITE-ORANGE	AIR BAG READY INDICATOR L (DEPLOY) TO SAFING SENSOR	611
RED-WHITE	SWITCH TO WARNING LAMP	42	WHITE-ORANGE	C.B. DOWN SWITCH	703
RED-WHITE	HEATER & A/C CONTROL SW. (HI-NORM) TO BLOWER MOTOR SW. RELAY	757	WHITE-ORANGE	RADIO SEEK	728
RED-WHITE	C.B. ON/OFF	718	WHITE-ORANGE	RELEASE LEVER WARN INDICATOR LAMP-CONSOLE	877
RED-WHITE	RADIO MEMORY	729	WHITE-ORANGE	ACTUATOR POSITION SENSOR LEFT REAR	842
RED-WHITE	SEAT REGULATOR SWITCH TO HORZ. MOTOR (RH)	987	WHITE-ORANGE	LEFT FRONT AIR INPUT RETURN	857
RED-WHITE	SEAT REGULATOR SWITCH TO HORZ. MOTOR (LH)	981	WHITE-ORANGE	ELECTRIC PVS TO MCU MODULE	392
RED-WHITE	MEMORY SEAT TO NEUTRAL SENSOR SWITCH	899	WHITE-ORANGE	INTERLOCK MODULE TO CENTER BUCKLE SWITCH	83
RED-WHITE	ELECTRONIC SHOCK SENSOR B	835	WHITE-ORANGE	RESET SWITCH TO MESSAGE CENTER	166
RED-WHITE	ELECTRIC SHIFT MODULE TO NEUTRAL START SWITCH	463	WHITE-ORANGE	MEMORY SEAT SWITCH LAMP DRIVE	272
RED-WHITE	HORIZONTAL POSITION SENSE	438	WHITE-PINK	LOW OIL LEVEL RELAY TO SENSOR	258
RED-WHITE	EMERGENCY WARNING FLASHER FEED	383	WHITE-PINK	EQU TO VACUUM SWITCH 2	213
RED-YELLOW	WINDOW REG. SW. TO WINDOW REG. MOTOR	334	WHITE-PINK	SERVO VENT SOLENOID TO CONTROL TRANSISTOR	146
RED-YELLOW	ELECTRONIC SHOCK SENSOR A	834	WHITE-PINK	BUZZER TO WARNING INDICATOR RELAY	160
RED-YELLOW	WARNING LAMPS FEED	640	WHITE-PINK	STARTER CONTROL TO INTERLOCK MODULE	33
RED-YELLOW	SUPERCHARGER SOLENOID #2	966	WHITE-PINK	FUEL FILLER DOOR RELEASE SWITCH TO FUEL FILLER DOOR RELEASE SOLENOID	482
RED-YELLOW	HEADLAMP DIMMER SWITCH FEED	15	WHITE-PINK	HEATER & A/C CONTROL SW. (DEFOG) TO DEFROST CONT. SOLENOID	775
RED-YELLOW	FUEL PRESSURE BOOST SOLENOID	236	WHITE-PURPLE	SENSOR AMPLIFY UNIT TO CONTROL UNIT #4	760
RED-YELLOW	WINDOW REG. MASTER CONT. SW. TO WINDOW REG. SW. FEED	328	WHITE-PURPLE	C.B. SQUELCH POT	701
TAN	EEC MODULE TO MALFUNCTION INDICATOR LITE	657	WHITE-PURPLE	AMPLIFIER SWITCH GROUND TO RIGHT REAR SPEAKER	824
TAN	MULTIPLEX SERVICE REMINDER	734	WHITE-PURPLE	POWER FEED-SWITCH TO FRONT AMPLIFIER	829
TAN	BOOST SENSOR TO CONTROL UNIT	748	WHITE-PURPLE	MEMORY MIRROR MODULE	895
TAN	FUEL INJECTOR #1 CYLINDER	555	WHITE-PURPLE	FUSE PANEL FEED TO RELAY	326
TAN	SWITCH TO FADER LEFT CHANNEL FEED	831	WHITE-PURPLE	DECK LID SWITCH TO ANTI-THEFT MODULE	26
			WHITE-PURPLE	AUTOLAMP AMPLIFIER TO SENSOR	218
			WHITE-PURPLE	FUSED ACCY FEED #1	296
			WHITE-RED	FUEL METERING CONTROL LEVER ACTUATOR 2 PLUS	312
			WHITE-RED	SPEAKER VOICE COIL FEED FRONT (R. CHANNEL) AMP INPUT	279
			WHITE-RED	COLD START TIMING RETARD SOLENOID	240
			WHITE-RED	H L SW. 70 CHIMES	257

* IN SOME CASES, THERE MAY BE ADDITIONAL CIRCUIT FUNCTIONS INCLUDED IN THE CIRCUIT DESCRIPTION LISTED.

STANDARD CIRCUIT CHART (BY COLOR)

COLOR	DESCRIPTION *	CIRCUIT
WHITE-RED	ELECT. ENG. CONTRL. MOD. TO TEST CONN #1	209
WHITE-RED	THERMACTOR DUMP VALVE FEED	190
WHITE-RED	OIL PRESSURE INDICATOR TO OIL PRESSURE SENDING UNIT	31
WHITE-RED	RH REAR TAIL LAMP BULB OUTAGE	103
WHITE-RED	AIR PUMP SOLENOID SIGNAL	100
WHITE-RED	FLASHER TO EMERGENCY WARNING SWITCH	385
WHITE-RED	ACTUATOR POSITION SENSOR RIGHT FRONT	841
WHITE-RED	LAMP RELAY TO MARKER LAMPS	667
WHITE-RED	PROCESSOR TO THERMACTOR CLUTCH RELAY	566
WHITE-RED	FUEL PUMP RESISTOR TO RELAY	922
WHITE-YELLOW	AIR BAG DIAGNOSTIC MODULE (DEPLOY) TO LH SENSOR	621
WHITE-YELLOW	C.B. UP SWITCH	707
WHITE-YELLOW	CHOKE RELAY TD MCU MODULE	391
WHITE-YELLOW	MESSAGE CENTER OUTPUT CLOCK TO DISPLAY	167
WHITE-YELLOW	POWER SERVO 10 CLIMATE CONTROL UNIT (AMP)	247
WHITE-YELLOW	SWITCH ON TO RELAY	275
YELLOW	ELECTRONIC CLUSTER FROM TRIP RESET SWITCH IN KEYBOARD	286
YELLOW	12 GA FUSE LINK	303
YELLOW	HORIZONTAL SEAT REG. MOTOR TO RELAY	179
YELLOW	LF WINDOW REG. SW. TD LF WINDOW REG. MOTOR	227
YELLOW	KEYLESS DOOR LOCK SWITCH DATA BIT 4 TO MODULE	122
YELLOW	TRAILER LH TURN SIGNAL	52
YELLOW	BATTERY TO LOAD	37
YELLOW	REARVIEW OUTSIDE MIRROR UP	410
YELLOW	POWER "THIGH" BOLSTER UP	491
YELLOW	EGR VALVE TO EEC MODULE FEED	362
YELLOW	C.B. B-DIGIT	716
YELLOW	MULTIPLEX WIPER RATE	700
YELLOW	ANTI-LOCK MODULE TO ANTI-LOCK CONTROL VALVE	678
YELLOW	ELECT SHIFT 4 x 4 MODULE TO MOTOR CONTROL COUNTER CLOCKWISE	777
YELLOW	AIR SUSPENSION DIODE SWITCH TO CONTROL MODULE	635
YELLOW	ALT POWER RELAY TO CONTROL MODULE	583
YELLOW	CONVERTIBLE TOP RELAY TO SWITCH	586
YELLOW	AIR SUSPENSION DIODE SWITCH TO CONTROL MODULE	635
YELLOW	DOOR WIRE	631
YELLOW	OIL PRESSURE SWITCH TO CUTOUT RELAY	669
YELLOW	AMPLIFIER TO RHEOSTAT	507
YELLOW	L.H. REMOTE MIRROR SOLENOID CONTROL	542
YELLOW	LEFT REAR AIR INPUT RETURN	859
YELLOW	SEAT BELT INDICATOR LAMP TO MODULE	871
YELLOW	VENT SWITCH,TO LEFT FRONT VENT MOTOR	887
YELLOW	TOP CONTROL RELAY TO MOTOR - UP	902
YELLOW-BLACK	COIL "A" TO DISTRIBUTORLESS IGNITION MODULE	850
YELLOW-BLACK	WINDOW SWITCH TO LEFT REAR MOTOR	884
YELLOW-BLACK	ACCELERATE DECELERATE SENSOR RETURN	837
YELLOW-BLACK	POWER RELAY BATTERY FEED	554
YELLOW-BLACK	RH FRONT SENSOR (LOW) TO MODULE	516
YELLOW-BLACK	RELAY TO ATC CONTROL	575
YELLOW-BLACK	LOW WASHER LEVEL TO SENSOR	793
YELLOW-BLACK	REMOTE DEFROST	727
YELLOW-BLACK	ELECT. ENG. CONTRL. MOD. TO TEST CONN #2	382
YELLOW-BLACK	GLOW PLUG TO CONTROL MODULE	472
YELLOW-BLACK	ELECTRONIC CONTROL UNIT TO ACCELERATION SOLENOID	46
YELLOW-BLACK	RADIO ANTENNA SWITCH FEED	137
YELLOW-BLACK	KEYLESS DOOR LOCK SWITCH DATA BIT 3 TO MODULE	121

COLOR	DESCRIPTION *	CIRCUIT
YELLOW-BLACK	SIGNAL UNIT LAMP TO FUEL SIGNAL RELAY	215
YELLOW-BLACK	LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT FRONT WINDOW REGULATOR MOTOR	313
YELLOW-SLACK	LEFT FRONT WINDOW REGULATOR SWITCH TO RIGHT REAR WINDOW REGULATOR MOTOR	319
YELLOW-LT BLUE	LEFT FRONT WINDOW REGULATOR SWITCH 10 LEFT REAR WINDOW REGULATOR MOTOR	316
YELLOW-LT BLUE	HEATER & NC CONTROL SW. (DE-ICE) TO CLIMATE CONTROL UNIT	248
YELLOW-LT BLUE	SPEED INPUT TO MESSAGE CENTER	136
YELLOW-LT BLUE	STARTING MOTOR TO STARTING MOTOR RELAY	113
YELLOW-LT BLUE	POSITION SENSE RETURN	435
YELLOW-LT BLUE	HORN SWITCH FEED	460
YELLOW-LT BLUE	SELECTOR SWITCH TO AFT AXLE TANK	675
YELLOW-LT BLUE	SEAT REGULATOR SWITCH TO FRONT MOTOR (RH)	984
YELLOW-LT BLUE	SEAT REGULATOR SWITCH TO FRONT MOTOR (LH)	990
YELLOW-LT BLUE	SEAT REGULATOR SWITCH TO FRONT MOTOR (LH)	978
YELLOW-LT BLUE	WINDOW SWITCH TO LEFT REAR MOTOR	885
YELLOW-LT GREEN	SEAT REGULATOR SWITCH TO REAR MOTOR (LH)	982
YELLOW-LT GREEN	AIR COND. CONTROL SW. TO FRESH-AIR RECIRC. DOOR SOLENOID	660
YELLOW-LT GREEN	SPLICE #2 TO MODULE	529
YELLOW-LT GREEN	SPLICE #3 TO PRESSURE SWITCH	534
YELLOW-LT GREEN	FLUID SWITCH TD GROUND STUD	550
YELLOW-LT GREEN	SPLICE #2 TO SPLICE #3	551
YELLOW-LT GREEN	SPLICE #2 TO COUP GROUND "B"	552
YELLOW-LT GREEN	ALT. SHUNT TO AMMETER	654
YELLOW-LT GREEN	MODULE TO RELEASE SOLENOID	664
YELLOW-LT GREEN	SEAT REGULATOR SWITCH TO REAR MOTOR (RH)	988
YELLOW-LT GREEN	POSITION SENSE ENABLE	437
YELLOW-LT GREEN	MOVABLE STEERING COLUMN SOLENOID FEED	375
YELLOW-LT GREEN	POWER STEERING PRESSURE SWITCH	330
YELLOW-LT GREEN	TRANSMISSION OVERDRIVE SWITCH TO HEAT MODULE	324
YELLOW-LT GREEN	HORN RELAY TO HORN	6
YELLOW-LT GREEN	WINDOW REGULATOR RELAY FEED	193
YELLOW-LT. GREEN	GROUND STUD TO SPLICE #2	548
YELLOW-RED	RH FRONT SENSOR (HIGH) TO MODULE	514
YELLOW-RED	BLOWER MOTOR SPEED CONTROLLER TO RESISTOR #2 (MED.)	752
YELLOW-RED	HEATER & NC CONTROL SW. TO BLOWER RELAY SW.	753
YELLOW-RED	COIL "B" TO DISTRIBUTORLESS IGNITION MODULE	851
YELLOW-RED	WINDOW REG. SW. TO WINDOW REG. MOTOR	333
YELLOW-RED	MCU MODULE TO KNOCK SENSOR	310
YELLOW-RED	HOT WATER TEMP. RELAY TO HOT WATER TEMP SENDING UNIT	45
YELLOW-RED	WINDSHIELD WIPER SW. 10 WINDSHIELD WIPER MOTOR	61
YELLOW-RED	SERVO FEEDBACK POTENTIOMETER SIGNAL TO AMPLIFIER	148
YELLOW-RED	STOP AND TURN BULB OUTAGE TO MESSAGE CENTER	135
YELLOW-WHITE	ALTERNATOR OUTPUT	36
YELLOW-WHITE	FUEL GAUGE TO FUEL GAUGE SENDER	29
YELLOW-WHITE	THERMAL SW. TO CLIMATE CONTROL UNIT	244
YELLOW-WHITE	SEAT PROCESSOR TO RECLINER MOTOR "UP"	439
YELLOW-WHITE	COIL "C" TO DISTRIBUTORLESS IGNITION MODULE	852
YELLOW-WHITE	ELECT SHIFT 4 X 4 MODULE TO MOTOR POSITION #1	762
YELLOW-WHITE	HEATED WINDSHIELD CONTROL TO HEATED WINDSHIELD SWITCH	738
YELLOW-WHITE	SEAT REGULATOR SWITCH TO HORZ. MOTOR (LH)	980
YELLOW-WHITE	SEAT REGULATOR SWITCH TO FRONT MOTOR (RH)	986
YELLOW-WHITE	ELECTRONIC THROTTLE VALVE POWER	925

* IN SOME CASES, THERE MAY BE ADDITIONAL CIRCUIT FUNCTIONS INCLUDED IN THE CIRCUIT DESCRIPTION LISTED.